

Owner's Manual for Maintenance and Safety

ATP 330 4X4 ATP 500 4X4



P#LARIS
The Way Out.

Read this manual carefully. It contains important safety information.

This is an adult vehicle only.

Operation is prohibited for those under 16 years of age.

AWARNING

Improper vehicle use can result in SEVERE INJURY or DEATH.



ALWAYS USE AN APPROVED HELMET AND PROTECTIVE GEAR



NEVER USE ON PUBLIC ROADS



NEVER CARRY PASSENGERS



NEVER USE WITH DRUGS OR ALCOHOL

NEVER:

- Operate without proper training or instruction.
- Operate on public roads. A collision can occur with another vehicle.
- Operate at speeds too fast for your skills or the conditions.
- Use ALCOHOL or DRUGS before or while operating this vehicle.
- Carry Passengers.

ALWAYS:

- Avoid paved surfaces, which may adversely affect handling and control.
- Use proper RIDING TECHNIQUES to avoid vehicle overturns on hills and rough terrain, and in turns.
- Wear eye protection, helmet and protective apparel.

READ OWNER'S MANUAL. FOLLOW ALL INSTRUCTIONS AND WARNINGS.


Part No. 9919515 Rev 02 PRINTED IN THE USA



AWARNING

The engine exhaust from this product contains chemicals known to cause cancer, birth defects or other reproductive harm.

A card containing important ATV safety information should be attached to the owner's manual on the next page. If you cannot locate this card, or if it has been removed, please call 1-800-342-3764 for assistance.





For 50 years we've been helping Polaris customers find The Way Out.

It's been a fun ride.
But then, after all these years,
That's what we're all about.

Visit our Web site at www.polarisindustries.com



Copyright 2004 Polaris Sales Inc. All information contained within this publication is based on the latest product information at the time of publication. Due to constant improvements in the design and quality of production components, some minor discrepancies may result between the actual vehicle and the information presented in this publication. Depictions and/or procedures in this publication are intended for reference use only. No liability can be accepted for omissions or inaccuracies. Any reprinting or reuse of the depictions and/or procedures contained within, whether whole or in part, is expressly prohibited.

Printed in U.S.A.

2005 ATP Owner's Manual P/N 9919515

WELCOME

Thank you for purchasing a Polaris vehicle, and welcome to our world-wide family of Polaris owners. We proudly produce an exciting line of utility and recreational products.

Polaris Recreational and Utility Vehicles

- Snowmobiles
- All-terrain vehicles (ATVs)
- Watercraft
- Victory motorcycles
- RANGER utility vehicles

We believe Polaris sets a standard of excellence for all utility and recreational vehicles manufactured in the world today. Many years of experience have gone into the engineering, design, and development of your Polaris vehicle, making it the finest machine we've ever produced.

For safe and enjoyable operation of your vehicle, be sure to follow the instructions and recommendations in this owner's manual. Your manual contains instructions for minor maintenance, but information about major repairs is outlined in the Polaris Service Manual and should be performed only by a Factory Certified Master Service Dealer (MSD) Technician.

Your Polaris dealer knows your vehicle best and is interested in your total satisfaction. Be sure to return to your dealership for all of your service needs during, and after, the warranty period.

We also take great pride in our Parts Apparel and Accessories (PAA) products, available through our online store at www.purepolaris.com. Have your accessories and clothing delivered right to your door!


POLARIS and POLARIS THE WAY OUT are registered trademarks of Polaris Industries Inc.

TABLE OF CONTENTS

WELCOME
VEHICLE IDENTIFICATION NUMBERS 6
SAFETY 7
FEATURES AND CONTROLS 33
OPERATION51
EMISSION CONTROL SYSTEMS 72
MAINTENANCE AND LUBRICATION 73
POLARIS PRODUCTS 119
TROUBLESHOOTING 120
SPECIFICATIONS 124
WARRANTY
INDEX 136

VEHICLE IDENTIFICATION NUMBERS

Record your ATV's identification numbers and key number in the spaces provided. Remove the spare key and store it in a safe place. Your key can be duplicated only by mating a Polaris key blank with one of your existing keys, so if both keys are lost, the ignition switch must be replaced.



Vehicle Model Number:	
Frame VIN (1):	
Lingine Senai Number (2)	
Key Number (3):	

Operator Safety

WARNING

Failure to follow the warnings contained in this manual can result in serious injury or death.

A Polaris ATV is not a toy and can be hazardous to operate. This vehicle handles differently than other vehicles, such as motorcycles and cars. A collision or rollover can occur quickly, even during routine maneuvers like turning, or driving on hills or over obstacles, if you fail to take proper precautions.

Read and understand your owner's manual and all warnings before operating a Polaris ATV.

Age Restrictions

This vehicle is an ADULT VEHICLE ONLY. Operation is prohibited for anyone under 16 years of age.

Know Your Vehicle

As the operator of the vehicle, you are responsible for your personal safety, the safety of others, and the protection of our environment. Read and understand your owner's manual, which includes valuable information about all aspects of your vehicle, including safe operating procedures.

Safety Training

When you purchased your new ATV, your dealer offered a hands-on safety training course that covers all aspects of vehicle safety. You were also provided with printed materials that explain safe operating procedures. You should review this information on a regular basis.

If you purchased a used Polaris ATV from a party other than a Polaris dealer, you can request this free safety training from any authorized Polaris dealer.

A Polaris ATV is an off-road vehicle. Familiarize yourself with all laws and regulations concerning the operation of this vehicle in your area.

We strongly advise you to strictly follow the recommended maintenance program outlined in your owner's manual. This preventive maintenance program is designed to ensure that all critical components on your vehicle are thoroughly inspected at specific intervals.

Operator Safety

The following signal words and symbols appear throughout this manual and on your ATV. Your safety is involved when these words and symbols are used. Become familiar with their meanings before reading the manual.



The safety alert symbol, on your vehicle or in this manual, alerts you to the potential for personal injury.

WARNING

The safety alert warning indicates a potential hazard that may result in serious injury or death.

CAUTION

The safety alert caution indicates a potential hazard that may result in minor personal injury or damage to the vehicle.

CAUTION

A *caution* indicates a situation that may result in damage to the vehicle.

NOTE:

A note will alert you to important information or instructions.

Operator Safety

WARNING

Serious injury or death can result if you do not follow these instructions and procedures, which are outlined in further detail within your owner's manual.

- Read this manual and all labels carefully, and follow the operating procedures described.
- Never operate an ATV without proper instruction. *Take a training course*. Beginners should receive training from a certified instructor. Contact an authorized Polaris ATV dealer or call Polaris at 1-800-342-3764 to find out about the training courses nearest you.
- Never allow anyone under 16 years of age to operate this ATV.
- Never permit a guest to operate the ATV unless the guest has read this manual and all product labels and has completed a certified safety training course.
- Always avoid operating an ATV on paved surfaces, including sidewalks, driveways, parking lots, and streets.
- Never operate an ATV on a public street, road or highway, including a dirt or gravel road.
- Never operate an ATV without wearing an approved helmet that fits properly. Always wear eye protection (goggles or face shield), gloves, boots, a long-sleeved shirt or jacket, and long pants.
- Never consume alcohol or drugs before or while operating an ATV.
- Never operate at excessive speeds. Travel at speeds appropriate for the terrain, visibility and operating conditions, and your experience.
- Never attempt wheelies, jumps or other stunts.
- Always inspect your ATV before each use to make sure it's in safe operating condition. Always follow the inspection and maintenance procedures and schedules outlined in your owner's manual.
- Always keep both hands on the handlebars and both feet on the footrests of the ATV during operation.
- Always travel slowly and use extra caution when operating on unfamiliar terrain. Be alert to changing terrain conditions.
- Never operate on excessively rough, slippery, or loose terrain.
- Always follow proper turning procedures as described in this manual. Practice turning at low speeds before attempting to turn at faster speeds. Do not turn at excessive speeds.

Operator Safety

- Always have the ATV inspected by an authorized Polaris dealer if it's been involved in an accident.
- Never operate on hills too steep for the ATV or for your abilities. Practice on smaller hills before attempting larger hills.
- Always follow proper procedures for climbing hills. Check the terrain carefully before ascend a hill. Never climb hills with excessively slippery or loose surfaces. Shift your weight forward. Never open the throttle suddenly or make sudden gear changes. Never go over the top of a hill at high speed.
- Always follow proper procedures for going downhill and for braking on hills. Check the terrain carefully before you start down a hill. Shift your weight backward. Never go down a hill at high speed. Avoid going down a hill at an angle, which would cause the vehicle to lean sharply to one side. Travel straight down the hill when possible.
- Always follow proper procedures for crossing the side of a hill.
 Avoid hills with excessively slippery or loose surfaces. Shift your
 weight to the uphill side of the ATV. Never attempt to turn the ATV
 around on any hill until you've mastered (on level ground) the turn ing technique outlined in this manual. Avoid crossing the side of a
 steep hill when possible.
- Always use proper procedures if you stall or roll backwards while climbing a hill. To avoid stalling, maintain a steady speed when climbing a hill. If you stall or roll backwards, follow the special procedure for braking described in this manual. Always dismount on the uphill side, or to either side if the ATV is pointed straight uphill. Turn the ATV around and remount following the procedure described in this manual.
- Always check for obstacles before operating in a new area. Never attempt to operate over large obstacles, such as rocks or fallen trees. Always follow proper procedures when operating over obstacles as described in this manual.
- Always be careful of skidding or sliding. On slippery surfaces like ice, travel slowly and use extra caution to reduce the chance of skidding or sliding out of control.
- Avoid operating the ATV through deep or fast-flowing water. If it's
 unavoidable, travel slowly, balance your weight carefully, avoid sudden movements, and maintain a slow and steady forward motion. Do
 not make sudden turns or stops, and do not make sudden throttle
 changes.

Operator Safety

- Wet brakes may have reduced stopping ability. Test your brakes after leaving water. If necessary, apply them lightly several times to allow friction to dry out the pads.
- Always check for obstacles or people behind the ATV before operating in reverse. When it's safe to proceed in reverse, move slowly and avoid turning at sharp angles.
- Always use the size and type of tires specified for your ATV, and always maintain proper tire pressure.
- Never modify an ATV through improper installation or use of accessories.
- Never exceed the stated load capacity for your ATV. Cargo must be properly distributed and securely attached. Reduce speed and follow the instructions in this manual for carrying cargo or towing. Allow a greater distance for braking.
- Always remove the ignition key when the vehicle is not in use to prevent unauthorized use or accidental starting.

FOR MORE INFORMATION ABOUT ATV SAFETY, call the Consumer Product Safety Commission at 1-800-638-2772, or call Polaris at 1-800-342-3764.

Equipment Modifications

We are concerned for the safety of our customers and for the general public. Therefore, we strongly recommend that consumers do not install on a Polaris ATV any equipment that may increase the speed or power of the vehicle, or make any other modifications to the vehicle for these purposes. Any modifications to the original equipment of the vehicle create a substantial safety hazard and increase the risk of bodily injury.

The warranty on your Polaris ATV is terminated if any equipment has been added to the vehicle, or if any modifications have been made to the vehicle, that increase its speed or power.

NOTE: The addition of certain accessories, including (but not limited to) mowers, blades, tires, sprayers, or large racks, may change the handling characteristics of the vehicle. Use only Polaris-approved accessories, and familiarize yourself with their function and effect on the vehicle.

SAFETY Operator Safety

WARNING

POTENTIAL HAZARD

Operating this ATV without proper instruction.

WHAT CAN HAPPEN

The risk of an accident is greatly increased if the operator does not know how to operate the ATV properly in different situations and on different types of terrain.

HOW TO AVOID THE HAZARD

Beginning and inexperienced operators should complete the certified training course offered by Polaris. Operators should regularly practice the skills learned in the course and the operating techniques described in the owner's manual.

For more information about the training course, contact an authorized ATV dealer or call Polaris at 1-800-342-3764.

WARNING

POTENTIAL HAZARD

Failure to follow the age recommendations for this ATV.

WHAT CAN HAPPEN

Severe injury and/or death could occur if a child under the minimum age recommendation operates an ATV.

Even though a child may be within the recommended age group for operating some ATVs, he/she may not have the skills, abilities, or judgment needed to operate an ATV safely and could be susceptible to accident or injury.

HOW TO AVOID THE HAZARD

No one under the age of 16 should operate a Polaris ATV.

Operator Safety

WARNING

POTENTIAL HAZARD

Carrying a passenger on an ATV.

WHAT CAN HAPPEN

Carrying a passenger greatly reduces the operator's ability to balance and control the ATV, which could cause an accident and injury to the operator and/or passenger.



HOW TO AVOID THE HAZARD

Never carry a passenger. The purpose of the long seat is to allow the operator to shift position as needed during operation. It is not intended for carrying passengers.


WARNING

POTENTIAL HAZARD

Carrying a passenger in the cargo box.

WHAT CAN HAPPEN

A passenger riding in the cargo box could be ejected from the vehicle unexpectedly or may contact moving components, both of which can result in severe injury or death.



HOW TO AVOID THE HAZARD

Never allow passengers to ride in the cargo box.

SAFETY Operator Safety

WARNING

POTENTIAL HAZARD

Operating an ATV on paved surfaces, including sidewalks, paths, parking lots, and driveways.

WHAT CAN HAPPEN

ATV tires are designed for off-road use. Operating on paved surfaces may seriously affect the handling and control of the ATV and could result in loss of control, accident, and/or injury.



HOW TO AVOID THE HAZARD

Avoid operating the ATV on pavement. If it's unavoidable, travel slowly and avoid sudden turns or stops.

WARNING

POTENTIAL HAZARD

Operating this ATV on public streets, roads or highways.

WHAT CAN HAPPEN

The ATV could collide with another vehicle.

HOW TO AVOID THE HAZARD

Never operate the ATV on any public street, road or highway, including dirt and gravel roads. In many states it's illegal to operate ATVs on public streets, roads and highways.



Operator Safety

WARNING

POTENTIAL HAZARD

Operating this ATV without wearing an approved helmet, eye protection and protective clothing.

WHAT CAN HAPPEN

Operating an ATV without an approved helmet increases the risk of a severe head injury or death in the event of an accident.

Operating without eye protection could result in an accident and could increase the chance of a severe injury in the event of an accident.



Always wear an approved helmet that fits properly.

Always wear eye protection (goggles or face shield), gloves, boots, long-sleeved shirt or jacket, and long pants.



WARNING

POTENTIAL HAZARD

Operating the ATV after consuming alcohol or drugs.

WHAT CAN HAPPEN

Consumption of alcohol and/or drugs could seriously affect operator iudgment. Reaction time may be slower and operator balance and perception could be affected.

Consuming alcohol and/or drugs before or while operating an ATV could result in an accident causing severe injury or death.

HOW TO AVOID THE HAZARD

Never consume alcohol or drugs before or while operating an ATV.





SAFETY Operator Safety

WARNING

POTENTIAL HAZARD

Operating the ATV at excessive speeds.

WHAT CAN HAPPEN

Excessive speed increases the operator's chance of losing control of the ATV, which can result in an accident.

HOW TO AVOID THE HAZARD

Always operate the ATV at a speed that's proper for the terrain, visibility and operating conditions, and your experience.

WARNING

POTENTIAL HAZARD

Attempting wheelies, jumps and other stunts.

WHAT CAN HAPPEN

Attempting stunts increases the chance of an accident, including an overturn.

HOW TO AVOID THE HAZARD

Never attempt wheelies, jumps, or other stunts. Avoid exhibition driving.



Operator Safety

WARNING

POTENTIAL HAZARD

Failure to inspect the ATV before operating.

Failure to properly maintain the ATV.

WHAT CAN HAPPEN

Poor maintenance increases the possibility of an accident or equipment damage.

HOW TO AVOID THE HAZARD

Always inspect your ATV before each use to make sure it's in safe operating condition.

Always follow the inspection and maintenance procedures and schedules described in the owner's manual.

WARNING

POTENTIAL HAZARD

Removing hands from the handlebars or feet from the footrests during operation.

WHAT CAN HAPPEN

Removing even one hand or foot can reduce ability to control the vehicle or could cause loss of balance and ejection from the ATV.

If the operator's foot is not firmly planted on the footrest, it could come into contact with the rear wheels and lead to accident or injury.

HOW TO AVOID THE HAZARD

Always keep both hands on the handlebars and both feet on the footrests of the ATV during operation.

SAFETY Operator Safety

WARNING

POTENTIAL HAZARD

Failure to use extra caution when operating the ATV on unfamiliar terrain.

WHAT CAN HAPPEN

Unfamiliar terrain may contain hidden rocks, bumps, or holes that could cause loss of control or overturn.



HOW TO AVOID THE HAZARD

Travel slowly and use extra caution when operating on unfamiliar terrain. Always be alert to changing terrain conditions.

WARNING

POTENTIAL HAZARD

Failure to use extra caution when operating on excessively rough, slippery or loose terrain.

WHAT CAN HAPPEN

Operating on excessively rough, slippery or loose terrain could cause loss of traction or loss of control, which could result in an accident or overturn.



HOW TO AVOID THE HAZARD

Do not operate on excessively rough, slippery or loose terrain until you've learned and practiced the skills necessary to control the ATV on such terrain.

Always use extra caution on rough, slippery or loose terrain.

Operator Safety

WARNING

POTENTIAL HAZARD

Turning improperly.

WHAT CAN HAPPEN

Improper turns could cause loss of control and lead to a collision or overturn.

HOW TO AVOID THE HAZARD

Always follow proper procedures for turning as described in the owner's manual.

Practice turning at slow speeds before attempting to turn at faster speeds.

Never turn at excessive speed.

WARNING

POTENTIAL HAZARD

Operating on excessively steep hills.

WHAT CAN HAPPEN

The vehicle may overturn.

HOW TO AVOID THE HAZARD

Never operate on hills too steep for the ATV or for your abilities. Never operate the ATV on hills steeper than 25° .

Practice on smaller hills before attempting large hills.

SAFETY Operator Safety

WARNING

POTENTIAL HAZARD

Climbing hills improperly.

WHAT CAN HAPPEN

Improper hill climbing could cause loss of control or overturn.

HOW TO AVOID THE HAZARD

Always follow proper procedures for climbing hills as described in the owner's manual.

Always check the terrain carefully before ascending any hill.

Never operate the ATV on hills steeper than 25° .

Never climb hills with excessively slippery or loose surfaces.

Shift your weight forward.

Never open the throttle suddenly while traveling uphill. The ATV could flip over backwards.

Never go over the top of any hill at high speed. An obstacle, a sharp drop, or another vehicle or person could be on the other side of the hill.



Operator Safety

WARNING

POTENTIAL HAZARD

Traveling downhill improperly.

WHAT CAN HAPPEN

Improperly descending a hill could cause loss of control or overturn.

HOW TO AVOID THE HAZARD

Always follow proper procedures for traveling down hills as described in the owner's manual. **NOTE:** A special technique is required when braking


while traveling downhill. See page 63.

Always check the terrain carefully before descending a hill.

Shift your weight backward.

Never travel down a hill at high speed.

Avoid traveling down a hill at an angle, which would cause the vehicle to lean sharply to one side. Travel straight down the hill when possible.



SAFETY Operator Safety

A WARNING

POTENTIAL HAZARD


Improperly crossing hills and turning on hills.

WHAT CAN HAPPEN

Improperly crossing or turning as hills could cause loss of control or overturn.

HOW TO AVOID THE HAZARD

Never attempt to turn the ATV around on any hill until you've mastered the turning technique (on level ground)



Avoid crossing the side of a steep hill.

When crossing the side of a hill:

Always follow proper procedures as described in the owner's manual.

Avoid hills with excessively slippery or loose surfaces.

Shift your weight to the uphill side of the ATV.



Operator Safety

A WARNING

POTENTIAL HAZARD

Stalling, rolling backwards or improperly dismounting while climbing a hill.

WHAT CAN HAPPEN

The vehicle could overturn.

HOW TO AVOID THE HAZARD

Maintain steady speed when climbing a hill.

If all forward speed is lost:

Keep your weight uphill.

Apply the front brake (or the single lever brake, gradually).

When fully stopped, apply the rear brake as well, then lock the parking brake.

If the ATV begins rolling backwards:

Keep weight uphill.

Never apply engine power.

Never apply the rear brake while rolling backwards.

Apply the front brake (or single-lever brake) gradually.

When fully stopped, apply the rear brake as well, and then lock the parking brake.

Dismount on uphill side, or to either side if ATV is pointed straight uphill.

Turn the ATV around and remount, following the procedure described in the owner's manual. See page 64.



Operator Safety

WARNING

POTENTIAL HAZARD

Improperly operating over obstacles.

WHAT CAN HAPPEN

Operating over obstacles could cause loss of control or overturn.

HOW TO AVOID THE HAZARD

Before operating in a new area, check for obstacles.

Avoid operating over large obstacles such as rocks and fallen trees when possible. If unavoidable, use extreme caution and always follow proper procedures as outlined in the owner's manual.

WARNING

POTENTIAL HAZARD

Skidding or sliding.

WHAT CAN HAPPEN

Skidding or sliding can cause loss of control.

If the tires regain traction unexpectedly, the ATV could overturn.

HOW TO AVOID THE HAZARD

On slippery surfaces such as ice, travel slowly and use extra caution to reduce the chance of skidding or sliding out of control.

WARNING

POTENTIAL HAZARD

Overloading the ATV or carrying/towing cargo improperly.

WHAT CAN HAPPEN

Overloading and towing can cause changes in vehicle handling, which could lead to loss of control or an accident.

HOW TO AVOID THE HAZARD

Never exceed the stated load capacity for this ATV.

Cargo should be properly distributed and securely attached.

Reduce speed when carrying cargo or pulling a trailer. Allow a greater distance for braking.

Always follow the instructions in the owner's manual for carrying cargo or pulling a trailer. See page 56.

Operator Safety

WARNING

POTENTIAL HAZARD

Operating the ATV through deep or fast-flowing water.

WHAT CAN HAPPEN

Tires may float, causing loss of traction and loss of control, which could lead to an accident or overturn.

HOW TO AVOID THE HAZARD

Avoid operating the ATV through deep or fast-flowing water. If it's unavoidable to enter water that exceeds the recommended maximum depth (see page 65), travel slowly, balance your weight carefully, avoid sudden movements, and maintain a slow and steady forward motion. Do not make sudden turns or stops, and do not make sudden throttle changes.

Wet brakes may have reduced stopping ability. Always test the brakes after leaving water. If necessary, apply them several times to let friction dry out the pads.

WARNING

POTENTIAL HAZARD

Improperly operating in reverse.

WHAT CAN HAPPEN

The ATV could collide with an obstacle or person, resulting in severe injury.

HOW TO AVOID THE HAZARD

Before shifting into reverse gear, always check for obstacles or people behind the ATV. When it's safe to proceed, back slowly.

Operator Safety

A WARNING

POTENTIAL HAZARD

Operating this ATV with improper tires, or with improper or uneven tire pressure.

WHAT CAN HAPPEN

Use of improper tires, or operation of the ATV with improper or uneven tire pressure, could cause loss of control or accident.

HOW TO AVOID THE HAZARD

Always use the size and type of tires specified in the owner's manual for the ATV.

Always maintain proper tire pressure.

WARNING

POTENTIAL HAZARD

Operating the ATV with improper modifications.

WHAT CAN HAPPEN

Improper installation of accessories or modification of the ATV may cause changes in handling which could lead to an accident.

HOW TO AVOID THE HAZARD

Never modify the ATV through improper installation or use of accessories. All parts and accessories added to the vehicle must be genuine Polaris Industries Inc. or equivalent components designed for use on this ATV and should be installed and used according to approved instructions. See your authorized Polaris ATV dealer for more information.

WARNING

POTENTIAL HAZARD

Operating on frozen bodies of water.

WHAT CAN HAPPEN

Severe injury or death can result if the ATV and/or the operator fall through the ice.

HOW TO AVOID THE HAZARD

Never operate the ATV on a frozen body of water.

Operator Safety

WARNING

Leaving the keys in the ignition can lead to unauthorized use of the vehicle resulting in serious injury or death. Always remove the ignition key when the vehicle is not in use.

WARNING

After any overturn or accident, have a qualified service dealer inspect the entire vehicle for possible damage, including (but not limited to) brakes, throttle and steering systems.

WARNING


Safe operation of this rider-active vehicle requires good judgement and physical skills. Persons with cognitive or physical disabilities who operate this vehicle have an increased risk of overturn and loss of control, which could result in severe injury or death.

A CAUTION

Exhaust system components are very hot during and after use of the vehicle. Hot components can cause serious burns and fire. Do not touch hot exhaust system components. Always keep combustible materials away from the exhaust system. Use caution when traveling through tall grass, especially dry grass.

Safety Decals and Locations

Warning decals have been placed on the ATV for your protection. Read and follow the instructions on each decal carefully. If a decal becomes illegible or comes off, contact your Polaris dealer to purchase a replacement. Replacement *safety* decals are provided by Polaris at no charge. The part number is printed on the decal.



Safety Decals and Locations

WARNING

- Never operate this ATV on HILLS steeper than 25 degrees 25°. To prevent flipover on hilly terrain, when going up or down, use throttle and brakes gradually.
- · REVERSE operation can be dangerous even at low speeds. Steering becomes difficult. To prevent flipover, avoid sudden braking or sharp turns.
- · Use OVERRIDE for reverse speed limiter with caution. To prevent loss of control, never activate override button with open throttle.
- When this ATV is not in operation or unattended, place shift in the park position.

WARNING



Operating this ATV if you are under the age of 16 increases your chance of severe injury or death.

NEVER operate this ATV if you are under age 16.

7172559

▲ WARNING

Improper ATV use can result in SEVERE INJURY or DEATH









ALWAYS USE AN APPROVED HELMET AND PROTECTIVE GFΔR

ON PUBLIC ROADS

NEVER CARRY PASSENGERS

NEVER USE WITH DRUGS OR ALCOHOL



NEVER operate:

- · without proper training or instruction
- at speeds too fast for your skills or the conditions
- on public roads a collision can occur with another vehicle
- · with a passenger passengers affect balance and steering and increase risk of losing control

ALWAYS:

- · use proper riding techniques to avoid vehicle
- overturns on hills and rough terrain and in turns
- avoid paved surfaces pavement may seriously affect handling and control

LOCATE AND READ OWNER'S MANUAL. FOLLOW ALL INSTRUCTIONS AND WARNINGS.

IF OWNER'S MANUAL IS MISSING, CONTACT A POLARIS DEALER FOR A REPLACEMENT.

9 1997, 2000

7172560

WARNING









WARNING

- Passengers can be thrown off. This can cause serious injury or death.
- Never carry passengers.







Safety Decals and Locations

AWARNING

IMPROPER TIRE PRESSURE OR OVERLOADING can cause loss of control resulting in SEVERE INJURY OR DEATH.

TIRE PRESSURE IN PSI (KPa): FRONT 5 (34,5) REAR 5 (34,5)

MAXIMUM WEIGHT CAPACITY (Gross Vehicle Weight)
INCLUDING MACHINE, DRIVER AND CARGO IS
1300 LBS. (590 kg)

MAXIMUM CARGO CAPACITY 350 LBS. (158 kg)

Reduce speed and allow greater distance for braking when carrying cargo. Overloading or carrying tall, off-center, or unsecured loads will increase your risk of losing control. Loads should be centered, carried as low as possible in box, and firmly secured to the rack. For stability on rough or hilly terrain, reduce speed and cargo. Do not block headlight. Be careful if load extends over the side of the rack or box.

Read Owner's Manual for more detailed loading information.

7172568

ATP 330

AWARNING

IMPROPER TIRE PRESSURE OR OVERLOADING can cause loss of control resulting in SEVERE INJURY OR DEATH.

TIRE PRESSURE IN PSI (KPa): FRONT 5 (34,5) REAR 5 (34,5)

MAXIMUM WEIGHT CAPACITY (Gross Vehicle Weight) INCLUDING MACHINE, DRIVER AND CARGO IS 1500 LBS. (680 kg)

Reduce speed and allow greater distance for braking when carrying cargo. Overloading or carrying tall, off-center, or unsecured loads will increase your risk of losing control. Loads should be centered, carried as low as possible in box, and firmly secured to the rack. For stability on rough or hilly terrain, reduce speed and cargo. Do not block headlight. Be careful if load extends over the side of the rack or box.

Read Owner's Manual for more detailed loading information.

7172574

F

ATP 500

WARNING

DO NOT TOW FROM RACK OR BUMPER. Vehicle damage or tipover may result causing severe injury or death. Tow only from tow hooks or hitch. Max. combined Front Rack and container Load 90 lbs. (41 kg) 7172569

G

Safety Decals and Locations

$\mathbf{A}\mathbf{W}\mathbf{\Delta}\mathbf{R}\mathbf{N}\mathbf{I}\mathbf{N}\mathbf{G}$

- Moving parts hazard under belt-clutch guard. To prevent serious injury, do not operate vehicle with guard removed.
- Do not modify engine or clutch. Doing so can cause part failure, possible imbalance, and excessive engine RPM, which can result in serious injury or death.

NO STEP

7172563

▲ WARNING

Pushing reverse override button may cause sudden increases in power and traction if too much throttle is applied. Loss of control or forward flipover may result, especially in AWD. See Owner's Manual.

7172564



MANUFACTURED BY: POLARIS IND. INC.

DATE:

VIN:

THIS VEHICLE IS AN ALL TERRAIN VEHICLE AND IS NOT INTENDED FOR USE ON PUBLIC ROADS.

CE VÉHICULE EST UN VÉHICULE TOUT TERRAIN QUI N'EST PAS DESTINÉ À ÊTRE UTILISÉ SUR LES CHEMINS PUBLICS.



ALL WHEEL DRIVE SWITCH

Do not push switch to engage AWD if the rear wheels are spinning. This may cause severe drive shaft and clutch damage. See your Owner's

Manuál

7079780

- Operation of this vehicle <u>ATTENTION</u> without the air filter element will severely damage the engine.
- Clean pre-filter element often, more frequent cleaning required in dusty conditions. Do not operate vehicle without pre-filter.

Canadian Certification Decal

 Specific carburetor jetting and adjustments are required depending on temperature and altitude. See your Owner's

Factory setting:

40° to 80° F. at 0-3000 feet (5° to 27° C. at 0-900 meters).

7170007

Under seat: ATP 330

Operation of this vehicle without the air filter element will severely damage the engine.

- · Clean pre-filter element often, more frequent cleaning required in dusty conditions. Do not operate vehicle without pre-filter.
- Operation of this vehicle without engine breather filter(s) can cause engine damage. Consult owner's manual or dealer for details.

ATTENTION . Specific

Manual.

carburetor jetting and adjustments are required depending on temperature and altitude. See vour Owner's Manual.

Factory setting:

40° to 80° F. at 0-3000 feet (5° to 27° C. at 0-900 meters).

7079902

Under seat: ATP 500

Safe Riding Gear

Always wear clothing suited to the type of riding. ATV riding requires special protective clothing for comfort and to reduce the chance of injury.


1. Helmet

Your helmet is the most important piece of protective gear for safe riding. A helmet can prevent a severe head injury.

Select an approved helmet that meets or exceeds your state's safety standards and bears either the Department of Transportation (DOT) label, the American National Standards Institute label (ANSI z90.1), or the Snell Memorial Foundation label.

2. Eye Protection

Do not depend on sunglasses for proper eye protection. A pair of goggles or a helmet face shield offer the best protection for your eyes. They should be kept clean and be of shatterproof design (bearing the markings z2.1 or VESC 8).



3. Gloves

Off-road style gloves with knuckle pads are the best for comfort and protection.

4. Boots


The best footwear is a pair of strong over-the-calf boots with heels, like moto-cross boots.

5. Clothing

Always wear long sleeves and long pants to protect arms and legs. Riding pants with kneepads and a jersey with shoulder pads provide the best protection.

FEATURES AND CONTROLS

Electrical Switches



WARNING

Activating the override switch while the throttle is open can cause loss of control, resulting in severe injury or death. Do not activate the override switch while the throttle is open.

Speedo Mode/Override Switch (1) (Reverse Speed Limiter) - This switch, if pressed while in any gear but reverse, will change the display mode of the speedometer (if equipped). To gain additional power while operating in reverse, depress the override switch before opening the throttle.

NOTE: The override switch also allows activation of All Wheel Drive in reverse, if the AWD switch is on.

Main Switch (2) - To start the engine, slide the stop switch to the center RUN position and turn the main key switch clockwise past the ON position. Release the key when the engine starts.

NOTE: Turn off the main switch to end all electrical power to the vehicle, including the cooling fan and lights.

WARNING


Leaving the keys in the ignition can lead to unauthorized use of the vehicle resulting in serious injury or death. Always remove the ignition key when the vehicle is not in use.

WARNING

A large key fob or key ring may contact the gas tank cap, causing an interruption to the electrical system and an unexpected engine shut-down during operation. This could result in serious injury or death. Do not attach a large key fob or key ring to the main switch.

Electrical Switches

Engine Stop Switch (3) - The engine will not start or run when the switch is in the OFF position. Its purpose is to provide the operator with a quick means of engine shutdown in case of an emergency. To stop the engine, slide the stop switch either right or left to the OFF position.




NOTE:

Turning off the engine stop switch will shut off all electrical power to the vehicle, with the exception of the cooling fan on some models. On those models, use the main switch to shut off the power to the cooling fan.

Light Switches

The light switch is located on the left handlebar (1). It's used to turn the lights on and off and to switch the lights from HI to LO on models equipped with HI/LO beams.



NOTE:

The lights won't work unless the key is in the ON position and the shut-off switch is in the RUN position.

WARNING

Operating the ATV on streets or roads, especially in darkness, could result in an accident and serious injury or death.

Your ATV is not equipped with highway-approved lights. It's designed for and must be used for *off-road use only*. Use caution and drive at reduced speeds in conditions of reduced visibility such as fog, rain and darkness.

WARNING

Do not start or operate an ATV with sticking or improperly operating throttle controls, which could cause an accident and lead to severe injury or death.

Always contact your dealer for service repairs if throttle problems arise.

Failure to check or maintain proper operation of the throttle system can result in an accident if the throttle lever sticks during operation.

Always check the lever for free movement and return before starting the engine. Also check occasionally during operation.

Throttle Lever

Engine speed and vehicle movement are controlled by pressing the throttle lever. The throttle lever (1) is spring loaded. Engine speed returns to idle when the lever is released.

This ATV is equipped with
Polaris Electronic Throttle Control
(ETC), which is designed to reduce the risk of a
frozen or stuck throttle. If the throttle cable should stick in an open
position when the operator releases the throttle lever, the engine will
stop, and power to the rear wheels will cease.



The Electronic Throttle Control (ETC) stops the engine in the event of a throttle system malfunction and is provided for your safety. Do not attempt to modify the ETC system or replace it with any after market throttle mechanisms.


Brake Lever

The front and rear brakes are applied by squeezing the brake lever (1) toward the handlebar. The front and rear brakes are hydraulically activated disc type brakes that are activated by only one lever.

WARNING

Operating the ATV with a spongy brake lever can result in loss of braking, which could cause an accident. Never operate the ATV with a spongy-feeling brake lever.

Always test brake lever travel and master cylinder fluid level before riding. When squeezed, the lever should feel firm. Any sponginess would indicate a possible fluid leak or low master cylinder fluid level, which must be corrected before riding. Contact your dealer for proper diagnosis and repairs.



Brake Fluid

Check the brake fluid level in the master cylinder before each use of the ATV. The master cylinder (2) is located on the left handlebar.

The fluid level can be seen through an indicator window (3) on the top of the master cylinder. This "eye" will appear dark when the fluid level is full. When fluid needs to be added, the eye will be clear.

WARNING

An over-full master cylinder may cause brake drag or brake lock-up, which could result in serious injury or death. Maintain brake fluid at the recommended level. Do not overfill.

NOTE: When checking the fluid level, the ATV must be on level ground with the handlebars straight. If the fluid level is low, add DOT 3 brake fluid only. DO NOT OVERFILL. See page 119 for the part numbers of Polaris products.

WARNING

Never store or use a partial bottle of brake fluid. Brake fluid is hygroscopic, meaning it rapidly absorbs moisture from the air. The moisture causes the boiling temperature of the brake fluid to drop, which can lead to early brake fade and the possibility of accident or severe injury. After opening a bottle of brake fluid, always discard any unused portion.


Parking Brake

WARNING

Operating the ATV while the parking brake is engaged could result in an accident and serious injury or death. Always check to be sure the parking brake is disengaged before operating.

Locking the Parking Brake

- 1. Squeeze and release the brake lever (1) two or three times, then squeeze and hold at full stroke.
- 2. Push the park brake lock (2) forward to engage the brake. Release the brake lever.
- 3. To release the parking brake lock, squeeze and release the brake lever. It will return to its unlocked position.



Important Safeguards

- Always place the gear shifter in park before engaging the parking brake.
- The parking brake may relax if left on for a long period of time. Always block the wheels to prevent rolling.
- Never depend on the parking brake alone if the ATV is parked on a hill. Always block the wheels on the downhill side of the ATV to prevent rolling. Another option is to park the ATV in a sidehill position.

Auxiliary Brake

WARNING

Aggressively applying the rear brake when backing down a hill may cause rear tipover, which could result in serious injury or death. If the rear brake is applied aggressively while moving forward, the rear wheels may skid and slide sideways, causing loss of control and serious injury or death.

Always use caution when applying the auxiliary foot brake. Do not apply the auxiliary foot brake aggressively.

The auxiliary foot brake (1) is located on the inside of the right floor board and is operated by the right foot. The auxiliary brake serves as a backup to the main brake system if the main system becomes inoperative. It activates the rear brakes only.



If the rear wheels slide while using the auxiliary brake, *reduce*

brake pedal pressure to brake the rear wheels without skidding.

Check the brake fluid level frequently for the auxiliary brake system. The reservoir is located under the seat or near the foot brake. Maintain the fluid level between the maximum and minimum marks.

Choke

The choke assists in starting a cold engine. Refer to the engine starting procedure on page 53 for correct choke and throttle settings during starting.

Fuel Valve

The fuel valve (1) is located on the left side panel. It has three positions:

OFF: For vehicle storage and when transporting.

ON: For normal operation.

RES: For reserve supply if main

supply is exhausted.

NOTE: There's about a 7 to 10 mile (11.2 to 16 km) range on

reserve gas. Always refill the gas tank as soon as possible after using the

reserve supply.


Always return valve to the ON position after refueling.

Fuel Tank

The fuel tank filler cap (2) is located directly below the handlebar. Use either leaded or unleaded gasoline with a minimum pump octane number of 87=(R+M/2) octane.

Fuel Filter

Have your dealer change the in-line fuel filter after every 100 hours of operation, or annually. Do not attempt to clean the fuel filter.





Fuel Safety

WARNING

Gasoline is highly flammable and explosive under certain conditions.

- Always exercise extreme caution whenever handling gasoline.
- Always refuel with the engine stopped, and outdoors or in a well ventilated area.
- Never fill a gas container while it's in the cargo box. Static electricity between the box and container could cause a spark.
- Do not smoke or allow open flames or sparks in or near the area where refueling is performed or where gasoline is stored.
- Do not overfill the tank. Do not fill the tank neck.
- If gasoline spills on your skin or clothing, immediately wash it off with soap and water and change clothing.
- Never start the engine or let it run in an enclosed area. Engine exhaust fumes are poisonous and can cause loss of consciousness or death in a short time.
- Turn the fuel valve off whenever the ATV is stored or parked.

WARNING

The engine exhaust from this product contains chemicals known to cause cancer, birth defects or other reproductive harm.

Operate this vehicle only outdoors or in well-ventilated areas.

Automatic Transmission Gear Selector

The transmission gear selector (1) is located on the right side of the vehicle.

H: High Gear


L: Low Gear N: Neutral

R: Reverse

P: Park

To shift into HIGH or PARK, you must first apply the auxiliary brake

to activate the high/park lock-out mechanism. When shifting out of HIGH or PARK, it's not necessary to apply the brake.



CAUTION

Shifting gears with the engine speed above idle or while the vehicle is moving could cause transmission damage. To change gears, stop the vehicle, and with the engine idling, move the lever to the desired gear. Apply the auxiliary brake before attempting to shift into high gear or park.

Ν

R

Whenever the ATV is left unattended, always place the transmission in park and lock the parking brake.

Maintaining shift linkage adjustment is important to assure proper transmission function. See your dealer if you experience any shifting problems.

Belt Life


To extend belt life, use low forward gear in heavy pulling situations and when operating at less than seven miles per hour for extended periods of time.

If towing the vehicle is necessary, shift the transmission into neutral for better mobility and to prevent damage to the belt.

Recoil Starter

If the battery is weak and cannot start the engine, use of the recoil starter (1) will allow vehicle operation until repairs can be made. The recoil starter is located on the right side of the machine.

Polaris 4-cycle engines are equipped with automatic decompressors. This makes recoil starting possible by allowing compression to "leak" at cranking



speeds. The decompressor senses when the engine is spinning fast enough to start and restores compression for starting.

- 1. Position the vehicle on a level surface, place the transmission in park and lock the parking brake (see page 38).
- 2. Grasp the recoil starter rope handle tightly and pull slightly until the starter mechanism engages.
- 3. Pull the rope abruptly to start the engine.

CAUTION

Extending the starter rope too far will cause damage to the recoil assembly. Do not extend the starter rope so far that it stops.

If the starter rope handle is not seated properly, water may enter the recoil housing and damage components. Make sure the handle is fully seated on the recoil housing, especially when traveling in wet areas.

FEATURES AND CONTROLS All Wheel Drive (AWD) System

Polaris 4 wheel drive ATVs are equipped with a unique, AWD system activated by a switch (1) on the right handlebar.



When the switch is on 2X4 (center position), the ATV is

in two wheel drive at all times and the differential is locked.

When the switch is on AWD (left position), the ATV is in AWD and the differential is locked. When in AWD, the front gearcase will automatically engage any time the rear wheels lose traction. When the rear wheels regain traction, the front gearcase will automatically disengage. There is no limit to the length of time the vehicle may remain in AWD.

NOTE: The override switch allows activation of AWD in reverse if the AWD switch is on. See page 33.

When the switch is on TURF (right position), the differential is open, allowing the inside wheel to rotate independently from the outside wheel during turns. Operate your Polaris ATP in TURF mode only to protect smooth, level surfaces from tire damage. Otherwise, switch out of TURF mode.

WARNING

Operating in TURF mode when on sloped, uneven, or loose terrain could cause loss of control and result in serious injury or death. One rear wheel may slip and lose traction or may lift up and grab when it touches the ground again.

Do NOT operate in TURF mode when climbing or descending hills, when sidehilling, or when operating on uneven, loose, or slippery terrain conditions such as sand, gravel, ice, snow, obstacles, and water crossings.

Simply switch the All-Wheel Drive (AWD) system out of TURF mode whenever it is not required.

All Wheel Drive (AWD) System Engaging the Front Gearcase

The AWD switch may be turned on or off while the vehicle is moving. Initially, the vehicle's electronic system will not enable the AWD until the engine RPM is below 3100. Once enabled, the AWD remains enabled until the AWD switch is turned off. If the switch is turned off while the front gearcase is moving, it will not disengage until the rear wheels regain traction.


Engage the AWD switch before getting into conditions where front wheel drive may be needed. If the rear wheels are spinning, release the throttle before switching to AWD.

CAUTION

Switching to AWD (or from TURF to 2X4) while the rear wheels are spinning may cause severe drive shaft and gearcase damage. Always switch to AWD (or to TURF from 2X4) while the rear wheels have traction or are at rest.

Instrument Cluster

Your ATV is equipped with an instrument cluster that senses vehicle speed from the right front wheel. The instrument cluster measures distance in miles as well as hours of operation. It also includes a reverse speed limiter function that limits the ATV's speed to approximately 7-9 mph. Refer to page 33 for additional information.



- 1. Rider Information Center
- 2. Speedometer needle in addition to showing vehicle speed, the needle flashes when a warning condition exists.
- 3. Speedometer

CAUTION

To prevent damage, wash the ATV by hand or with a garden hose using mild soap. Do not use alcohol to clean the instrument cluster. Immediately clean off any gasoline that splashes on the instrument cluster.

Instrument Cluster

Rider Information Center

The rider information center is located in the instrument cluster. All segments will light up for 2.5 seconds at start-up.

NOTE: If the instrument cluster fails to illuminate, a battery over-voltage may have occurred and the instrument cluster may have shut off to protect the electrical system. If this occurs, take the ATV to your Polaris dealer for proper diagnosis.

1. **Gear Indicator -** As the shift lever is moved, this indicator shows the gear the transmission is in:

H = High Range


L = Low Range

N = Neutral

R = Reverse

P = Park (if equipped)

 AWD Indicator - This indicator illuminates when the electrical portion of the AWD system is enabled.



- 3. Engine Hour Display Indicator
- 4. Service Interval/Diagnostic Mode Indicator
- 5. **Low Battery and Over Voltage -** This warning usually indicates that the ATV is being operated at an RPM too low to keep the battery charged. A low battery warning may also occur under normal operation if the machine is at idle and high electrical load (lights, cooling fan, accessories) is applied. Driving at a higher RPM or connecting a battery charger will usually clear the warning.
- 6. Odometer/Tachometer/Tripmeter/ Hour Meter
- 7. **Check Engine Warning Indicator -** The word HOT will display alphanumerically when the engine is overheating. Do not continue to operate the ATV is this warning appears or serious engine damage could result.
- 8. Mode Indicator

Instrument Cluster

Rider Information Center

The rider information center has 4 standard modes:

Mode 1 - Odometer

Mode 2 - Tripmeter

Mode 3 - Total Service Hours

Mode 4 - Tachometer

The reverse override button on the left handlebar is also the *mode* button.

NOTE:

If using the mode button to program the rider information center, or to toggle through the options, the machine cannot be in reverse.

Mode 1 - Odometer

The odometer records the miles traveled by the ATV.

Mode 2 -Trip Meter

The trip meter records the miles traveled by the ATV on each trip if it's reset before each trip. To reset the trip meter, select the trip meter mode. Press and hold the mode button (override button) until the total changes to θ .

NOTE:

In the Rider Information Center, the trip meter display contains a decimal point, but the odometer displays without a decimal point.

Mode 3 - Hour Meter

This mode logs the total hours the engine has been in operation.

Mode 4 - Tachometer

The engine RPM is displayed digitally.

NOTE:

Small fluctuations in the RPM from day to day may be normal because of changes in humidity, temperature and elevation.

Instrument Cluster Rider Information Center

Diagnostic Mode

The diagnostic mode is for informational purposes only. Please return your ATV to your dealer for all major repairs.

As long as the gauge is in the diagnostic mode, the wrench icon will remain lit.

To leave the diagnostic mode, either shift the machine out of neutral or turn the key switch off and on.

NOTE: Any movement of the tires will also take the machine out of the diagnostic mode.

To enter the diagnostics mode:

- 1. Turn the key switch off and wait 10 seconds.
- 2. Set the parking brake and shift the transmission into neutral.
- 3. Hold the mode/reverse override button and turn the key switch on.
- 4. Release the switch as soon as the display is activated.

The initial screen display refers to the software version installed in your ATV. This information is displayed briefly.

Use the mode/reverse override button to toggle through the diagnostic screens.

Screen 1: Battery voltage

Screen 2: Tachometer

Screen 3: AWD diagnostic

This gauge indicates whether or not current is flowing through the AWD coil (only on models with switchable AWD).

Screen 4: Gear circuit diagnostic

This screen displays the resistance value (in ohms) being read at the gear switch input of the gauge.

Instrument Cluster Rider Information Center

Diagnostic Mode

Screen 5: Programmable service interval

The purpose of the programmable service interval is to provide the consumer and dealer with a convenient reminder for routine maintenance. When your vehicle leaves the factory, this feature is set at 50 hours. You must enable the programmable service interval before it can be used.

Once the service interval mode is set with the hours when service is due, the hours of actual engine operation are subtracted from the set hours until θ is reached. When the counter reaches θ , the wrench icon will flash quickly for 5 seconds each time the vehicle is started as a reminder that the periodic maintenance is due.

To set the hours, press and hold the mode/override button until the wrench icon flashes. When it begins to flash, release the button. The setting will increase by one hour each time the button is pressed. Pressing and holding the button will allow the numbers to escalate much faster. When the desired time increment is displayed, release the button and wait for the wrench to stop flashing. When the wrench stops blinking, your service hours are set.

NOTE: If you scroll past the intended number, hold the button down until the count turns over to 0. You can then reset the number.

If the service interval is enabled on your ATV and you wish to turn it off, toggle to the service interval mode. Press and hold the mode button for approximately 7 seconds until the word *OFF* appears in the Rider Information Center.

Screen 6: Miles/Kilometers toggle

The display in the tripmeter and odometer can be changed to display either kilometers or miles. The current display mode will be shown as KM or MP. To change, hold in the mode button until the letters flash, then press and release the button once. When the display stops flashing, the mode has been set.

Break-In Period

The break-in period for your new Polaris ATV is defined as the first ten hours of operation, or the time it takes to use the first two full tanks of gasoline. No single action on your part is as important as following the procedures for a proper break-in. Careful treatment of a new engine will result in more efficient performance and longer life for the engine. Perform the following procedures carefully.

CAUTION

Excessive heat build-up during the first three hours of operation will damage close-fitted engine parts. Do not operate at full throttle or high speeds for extended periods during the first three hours of use.

Use of any oils other than those recommended by Polaris may cause serious engine damage. We recommend the use of Polaris Premium 4 Synthetic Oil for your 4-cycle engine.

ADD 8 OZ. →

NORMAL

FULL

- 1. Fill the fuel tank with gasoline. See page 40.
- Check the oil level on the dipstick. See pages 1
 80 and 83. Add Polaris
 Premium 4 Synthetic Oil if necessary to maintain the oil level in the normal (safe) operating range (1).
- 3. Drive slowly at first. Select an open area that allows room to familiarize yourself with vehicle operation and handling.
- 4. Vary throttle positions. Do not operate at sustained idle.
- 5. Perform regular checks on fluid levels, controls and areas outlined on the daily pre-ride inspection checklist. See page 52.
- 6. Pull only light loads.
- 7. During the break-in period, change both the oil and the filter at 25 hours or one month.

OPERATION Pre-Ride Inspection

A WARNING

If a proper inspection is not done before each use, severe injury or death could result. Always inspect the vehicle before each use to ensure it's in proper operating condition.

Pre-Ride Checklist			
item	Remarks	See Page	
Brake system / lever travel	Ensure proper operation	36, 90	
Brake fluid	Ensure proper level 37		
Auxiliary brake	Ensure proper operation 39, 9		
Front suspension	Inspect, lubricate if necessary	77	
Rear suspension	Inspect, lubricate if necessary	77	
Steering	Ensure free operation	_	
Tires	Inspect condition and pressure	30,100, 125	
Wheels / fasteners	Inspect, ensure fastener tightness	99	
Frame nuts, bolts, fasteners	Inspect, ensure tightness	_	
Fuel and oil	Ensure proper levels	80, 83	
Coolant level (ATP 500)	Ensure proper level 89		
Coolant hoses (ATP 500)	Inspect for leaks -		
Throttle	Ensure proper operation 35, 9		
Indicator lights / switches	es Ensure operation		
Engine stop switch	gine stop switch Ensure proper operation		
Air filter, pre-filter	Inspect, clean 1		
Air box sediment tube	Drain deposits whenever visible	_	
Headlamp	Check operation, apply Polaris dielectric grease when lamp is replaced	102	
Brake light / tail lamp	Check operation, apply Polaris dielectric grease when lamp is replaced	103	
Riding gear	Wear helmet, goggles, protective clothing	32	

Starting the Engine Starting a Cold Engine

A WARNING

Engine exhaust contains poisonous carbon monoxide and can cause loss of consciousness resulting in severe injury or death. Never run an engine in an enclosed area.

CAUTION

Operating the vehicle immediately after starting could cause engine damage. Allow the engine to warm up for several minutes before operating the vehicle.

- 1. Place the transmission in park and lock the parking brake.
- 2. Turn the fuel tank valve on.
- 3. Sit on the vehicle.
- 4. Pull the choke knob out until it stops (1).

NOTE: The variable choke is fully on when the knob is pulled completely out. The choke is off when the knob is pushed completely in. The choke can be adjusted gradually, depending on how much choke is needed for starting. Be sure the choke is off during operation, as excess fuel washing into the engine oil will increase wear on engine components.

5. Turn the engine stop switch to RUN.

NOTE: Do not press the throttle while starting the engine.

- 6. Turn the ignition key past the ON position to engage the starter. Activate the starter for a maximum of five seconds, releasing the key when the vehicle starts. If the engine does not start, release the starter and wait five seconds. Then activate the starter for another five seconds. Repeat this procedure until the engine starts.
- 7. If the engine slows or stops, position the choke knob half way in to allow proper engine warm up.
- 8. Vary the engine RPM slightly with the throttle to aid in warm-up. When the engine idles smoothly, push the choke all the way in.

Starting the Engine

Starting a Warm Engine

Warm engines do not normally require the use of the choke. Using the choke can cause the spark plug to become wet fouled.

- 1. Position the vehicle on a level surface with the transmission in park.
- 2. Lock the parking brake, turn the fuel tank valve to ON, sit on the vehicle, and turn the engine stop switch to RUN.
- 3. If the engine has cooled to a point where it does not readily start, intermittent use of the choke button (pulled half way out) may be necessary.
- 4. If the engine is over-choked when warm, depress the throttle lever fully while cranking to aid in starting.
- 5. Release the throttle lever immediately after the engine starts. If the engine does not start and all conditions are favorable, change the spark plug and try again.

Cold Weather Operation for 4-Cycle Engines

If the ATV is used year-round, check the oil level frequently. A rising oil level could indicate the accumulation of water in the bottom of the oil tank. Water in the bottom of the tank can lead to engine damage and must be drained. Water accumulation increases as outside temperature decreases.


See your Polaris dealer for engine heater kits, which provide quicker warm-ups and easier starting in colder weather.

Hauling Cargo

WARNING

Overloading the vehicle or carrying or towing cargo improperly can alter vehicle handling and may cause loss of control or brake instability. Always follow these precautions when hauling cargo:

- Never exceed the stated load capacity for this vehicle.
- Reduce speed and allow a greater distance for braking.
- When operating over rough or hilly terrain, reduce speed and cargo to maintain stable driving conditions.
- WEIGHT DISTRIBUTION in the cargo bed should be as far forward and as low as possible. Carrying a high load raises the center of gravity and creates a less stable operating condition. Reduce load weight when cargo is high. When handling off-centered loads that cannot be centered, secure the load and operate with extra caution.
- ALL LOADS MUST BE SECURED BEFORE OPERATING.
 Unsecured loads may shift and create unstable operating conditions, which could result in loss of control of the vehicle. Always be sure that the cargo bed is lowered and latched before moving the vehicle.
- EXTREME CAUTION MUST BE USED when operating with loads extending beyond the rack or cargo bed. Stability and maneuverability may be adversely affected, causing the machine to overturn.
- Carrying a load on only the front rack or cargo bed may cause an imbalanced condition and increases the possibility of vehicle overturn. Balance loads proportionally between the front rack and cargo bed, but do not exceed the stated load capacity.
- Use extreme caution when applying brakes with a loaded vehicle. Avoid terrain or situations that may require backing downhill.
- Always attach the tow load to the hitch point.
- The vehicle should never exceed 10 mph (16 kph) while towing a load on a level surface. Vehicle speed should never exceed 5 mph (8 kph) when towing loads in rough terrain, while cornering, or while ascending or descending a hill.
- Do not obstruct the headlight when loading the front rack.



Your ATV has been designed to carry or tow a certain amount of load. Always read and understand the load distribution warnings listed on the warning labels, and never exceed the specified weights.

Cargo weight should be mounted as low as possible. When operating over rough or hilly terrain, reduce speed and cargo to maintain stable driving conditions.

- 1. Always load the cargo box with the load as far forward as possible.
- 2. Always operate the vehicle with extreme caution whenever hauling or towing loads. Balance, handling, and control may be affected.
- 3. Slow down.
- 4. The cargo box dump latch must be securely latched before loading and operating. Unintentional box tilting will result if weight is placed in the rear of the box and the latch is not secured.

Maximum Towing Capacities

Do not exceed the following maximum capacities when towing. Maximum grade while trailer towing is 15°. Do not tow any trailer on a grade steeper than 15°.

	Towing Load (Level Ground)	Vertical Hitch Weight
ATP 330 4X4	1000 lbs. (454 kg)	100 lbs. (45.4 kg)
ATP 500 4X4	1225 lbs. (556 kg)	120 lbs. (54.4 kg)

Belt Life

Use low forward gear when hauling or towing heavy cargo to extend belt life.

Hauling Cargo Dumping Cargo

- 1. Select a level site to dump the cargo box. Do not attempt to dump or unload the vehicle while parked on an incline.
- 2. Place the transmission in park and set the parking brake.
- 3. Dismount the vehicle.
- 4. Lower the tailgate.

A WARNING

If cargo weight is placed toward the rear of the cargo box, the load may dump unexpectedly and cause serious injury. When loading cargo, always position the weight as far forward and as low as possible.

- 5. Pull the cargo box release lever upward.
- 6. Lift the front of the cargo box and dump the cargo.
- 7. Lower the cargo box and make sure the release latch is secured.
- 8. Secure the tailgate.

WARNING

Operating with the cargo box in the raised position can cause serious injury and damage to the vehicle. The cargo box could close unexpectedly and injure the driver. The rear tires will also catch the rear of the bed, damaging the vehicle and creating hazardous driving conditions.

Never operate this vehicle with the cargo box in the raised position.

OPERATION Driving Safely

Driving Safety Driving Procedures



- 1. Sit upright with both feet on the footrests and both hands on the handlebars.
- 2. Start the engine and allow it to warm up, then shift the transmission into gear.
- 3. Check your surroundings and determine your path of travel.
- 4. Release the parking brake.
- 5. Slowly depress the throttle with your right thumb and begin driving. Vehicle speed is controlled by the amount of throttle opening.
- 6. Drive slowly. Practice maneuvering and using the throttle and brakes on level surfaces.

Driving Safely Making Turns



Your Polaris ATV is equipped with a rear differential that functions as a solid rear axle, driving both rear wheels equally when the ATP is in either 2X4 or 4X4 mode. This means that the wheel on the outside of a turn must travel a greater distance than the inside wheel, causing the inside tire to slip traction slightly.

To make a turn, steer in the direction of the turn, leaning your upper body to the inside of the turn while supporting your weight on the outer footrest. This technique alters the balance of traction between the wheels, allowing the turn to be made smoothly. The same leaning technique should be used for turning in reverse.

NOTE: Practice making turns at slow speeds before attempting to turn at faster speeds.

WARNING

Turning at sharp angles or at excessive speeds can result in vehicle overturn and lead to serious injury. Avoid turning at sharp angles. Never make turns at high speeds.

Driving Safely

Driving on Slippery Surfaces



Whenever riding on slippery surfaces such as wet trails or loose gravel, or during freezing weather, follow these precautions:

- 1. Slow down when entering slippery areas.
- 2. Maintain a high level of alertness, reading the trail and avoiding quick, sharp turns which can cause skids.
- 3. Correct a skid by turning the handlebars in the direction of the skid and shifting your body weight forward.
- 4. Driving with AWD engaged can assist in controlling the vehicle in slippery areas.

CAUTION

Severe damage to drive train may occur if the AWD is engaged while the wheels are spinning. Always engage AWD when the wheels have traction or are at rest.

A WARNING

Failure to exercise care when operating on slippery surfaces can result in loss of tire traction and cause loss of control, accident, and serious injury or death.

Never apply the brakes during a skid.


Do not operate on excessively slippery surfaces.

Always reduce speed and use additional caution.

Driving Safely Driving Uphill

Whenever traveling uphill, follow these precautions:

- 1. Always travel straight uphill.
- 2. Avoid steep hills (25° maximum).
- Keep both feet on the footrests. 3.
- 4. Transfer your weight forward.
- 5. Proceed at a steady rate of speed and throttle opening.
- 6. Remain alert and prepared to take emergency action. This may include quick dismounting of the vehicle.



If all forward speed is lost:

Keep your weight uphill.

Apply the front brake (or the single lever brake, gradually). When fully stopped, apply rear brake as well, then lock the park brake.

If the ATV begins rolling backwards:

Keep your weight uphill. Never apply engine power. Never apply the rear brake while rolling backwards.

Apply the front brake (or single-lever brake, gradually). When fully stopped, apply the rear brake as well, and then lock the parking brake.

Dismount on uphill side, or to either side if ATV is pointed straight uphill. Turn the ATV around and remount, following the procedure described on page 64.

WARNING

Braking and handling are greatly affected when operating in hilly terrain. Improper procedure could cause loss of control or overturn and result in serious injury or death.

Avoid climbing steep hills (25° maximum).

Use extreme caution when operating on hills, and follow proper operating procedures outlined in the owner's manual.

OPERATION Driving Safely



WARNING

Improperly crossing hills or turning on hills can result in loss of control or vehicle overturn, resulting in severe injury or death. Avoid crossing the side of a hill when possible. Follow proper procedures as outlined in the owner's manual.

Sidehilling can be a dangerous type of driving and should be avoided if at all possible. If you do enter into a situation where sidehilling is necessary, follow these precautions:

- Slow down.
- 2. Lean into the hill, transferring your upper body weight toward the hill while keeping your feet on the footrests.
- 3. Steer slightly into the hill to maintain vehicle directions.

NOTE: If the vehicle begins to tip, quickly turn the front wheel downhill, if possible, or dismount on the uphill side *immediately*!

Driving Safely Driving Downhill



Whenever descending a hill, follow these precautions:

- 1. Proceed directly downhill.
- 2. Transfer your weight to the rear of the vehicle.
- 3. Slow down.
- 4. Apply the brakes *slightly* to aid in slowing.

Familiarize yourself with operation of the auxiliary rear brake pedal for additional braking in the event of normal service brake loss.

WARNING

Excessive speed can cause loss of control and lead to serious injury or death. Always operate slowly when traveling downhill.

Driving Safely Turning Around on a Hill

WARNING


Improper hill climbing procedures could cause loss of control or overturn and result in serious injury or death.

Avoid climbing steep hills (25° maximum).

Use extreme caution when operating on hills, and follow proper operating procedures outlined in the owner's manual.

If the vehicle stalls while climbing a hill, never back it down the hill! One maneuver that can be used when it's necessary to turn around while climbing a hill is the K-turn:

- 1. Stop and lock the parking brake while keeping body weight uphill.
- 2. Leave transmission in forward and shut off the engine.
- 3. Dismount on the uphill side of the vehicle, or on the left if the vehicle is pointing straight uphill.
- 4. Staying uphill of the vehicle, turn the handlebars full left.
- 5. While holding the brake lever, release the parking brake lock and slowly allow the vehicle to roll around to your right until it's pointing across the hill or slightly downward.
- 6. Lock the parking brake and remount the vehicle from the uphill side, keeping body weight uphill.
- 7. Restart the engine with the transmission still in forward.
- 8. Release the parking brake and proceed *slowly*, controlling speed with the brake, until the vehicle is on more level ground.



Driving Safely Driving Through Water



Your ATV can operate through water with a maximum recommended depth equal to the bottom of the footrests (1). Follow these procedures when operating through water:

- 1. Determine water depths and current before crossing.
- 2. Choose a crossing where both banks have gradual inclines.
- 3. Proceed slowly, avoiding rocks and obstacles if possible.
- 4. After crossing, dry the brakes by applying light pressure to the lever until braking action is normal.

NOTE: Avoid operating the vehicle through deep or fast-flowing water. If you cannot avoid water that exceeds the recommended maximum depth, go slowly, balance your weight carefully, avoid sudden movements, and maintain a slow and steady forward motion. Do not make sudden turns or stops, and do not make sudden throttle changes.

Driving Safely Driving Through Water

After running the vehicle in water, it's *critical* to have it serviced as outlined in the maintenance chart. See page 73. The following areas need special attention: engine oil, transmission oil, front and rear gearcases and all grease fittings.

NOTE: If water has been ingested into the PVT, follow the procedure on page 71 for drying out the PVT.

If your vehicle becomes immersed, and it's impossible to take it to a dealer before starting it, follow the steps described on page 107. Have the vehicle serviced by your dealer promptly.

CAUTION

Major engine damage can result if the vehicle is not thoroughly inspected after operation in water. Perform the services outlined in the maintenance chart.

If your vehicle becomes immersed or is operated in water that exceeds the footrest level, take it to your dealer for service before starting the engine.

Driving Safely Driving Over Obstacles



Be alert! Look ahead and learn to read the terrain. Be constantly alert for hazards such as logs, rocks and low hanging branches.

WARNING

Severe injury or death can result if your vehicle comes in contact with a hidden obstacle. Not all obstacles are immediately visible. Travel with caution in unfamiliar terrain.

Driving Safely

Driving in Reverse

Follow these precautions when operating in reverse:

- 1. Always avoid backing downhill.
- 2. Back slowly.
- 3. When in reverse, apply the brakes *lightly* for stopping.
- 4. Avoid turning at sharp angles in reverse.
- 5. Never open the throttle suddenly while backing.



WARNING

Failure to use caution when operating in reverse can result in serious injury or death. Before shifting into reverse, always check for obstacles or people behind the vehicle. When it's safe to proceed, back slowly.

Do not use the override switch unless additional power is required for vehicle movement. Use with caution.

Avoid backing on inclines, and avoid turning at sharp angles.


NOTE:

Most Polaris ATVs are equipped with a reverse speed limiter. The override button should be used with caution as rearward vehicle speed is greatly increased. Do not operate at wide open throttle. Open the throttle just enough to maintain a desired speed.

CAUTION

Excessive throttle operation while in the speed limit mode may cause fuel to build in the exhaust, resulting in engine popping and/or engine damage.

Driving Safely Parking on an Incline



Avoid parking on an incline if possible. If it's unavoidable, follow these precautions:

- 1. Turn the engine off.
- 1. Place the transmission in park.
- 2. Set the parking brake.
- 3. Always block the rear wheels on the downhill side as shown in illustration.
- 4. Shut off the fuel supply.

OPERATION

PVT System

The basic operation of the Polaris PVT system is dependent on engine speed and vehicle torque requirements. As engine speed increases, the force exerted on the movable drive sheave by the flyweights also increases. This, in turn, increases the amount of "pinch" applied to the drive belt. Similarly, if the engine speed decreases, the amount of centrifugal force decreases, reducing the amount of belt "pinch."

On Polaris ATVs, the approximate gear ratio difference between high and low range is 1:2.25. This difference in gearing affects the operation of the PVT, especially at speeds less than 7 MPH, due to the system's dependence on engine speed.

For example, when operating at a ground speed of 3 MPH in low range, the engine speed would be around 3000 RPM. This is well above the engagement speed of 1200 - 1400 RPM. However, in high range at 3 MPH, the engine would be running at only 1500 RPM. Whenever operating this close to the engagement speed, the engine may be running at a speed too low to provide the "pinch" needed to prevent belt slip. Belt slip is responsible for creating the excessive heat that destroys belts and causes outer clutch covers to fail.

By switching to low range while operating at low ground speeds, the air temperature in the clutch cover is reduced by almost 160 degrees. Reducing the temperature inside the clutch cover extends the life of the PVT components (belt, cover, etc.).

When To Use Low Range vs. High Range

Following is a guideline for when to use low range and high range.

Low Range

- When basic operation is at speeds less than 7 MPH
- · For heavy pulling
- When operating in rough terrain (swamps, mountains, etc.) at low ground speeds

High Range

- When basic operation is at speeds greater than 7 MPH
- When operating at high ground speeds

OPERATION

PVT System

WARNING

Failure to comply with the instructions in this warning can result in severe injury or death.

Do not modify any component of the PVT system. Doing so may reduce its strength so that a failure may occur at a high speed. The PVT system has been precision balanced. Any modification will cause the system to be out of balance, creating vibration and additional loads on components.

The PVT system rotates at high speeds, creating large amounts of force on clutch components. Extensive engineering and testing has been conducted to ensure the safety of this product. However, as the owner, you have the following responsibilities to make sure this system remains safe:

Always follow all recommended maintenance procedures. See your dealer as outlined in the owner's manual.

This PVT system is intended for use on Polaris products only. Do not install it in any other product.

Always make sure the PVT housing is securely in place during operation.

PVT Drying

There may be some instances when water is accidently ingested into the PVT system. Use the following instructions to dry it out before operating:

- 1. Remove the drain plug and allow the water to drain. Replace the drain plug.
- 2. Start the engine and shift the transmission into park. Apply varying throttle for 10-15 seconds to expel the moisture and air-dry the belt and clutches. Do not hold the throttle wide open for more than 10 seconds.
- 3. Allow the engine RPM to settle to idle speed, then shift the transmission to the lowest available range.
- 4. Test for belt slippage. If the belt slips, repeat the process.
- 5. Take the vehicle to your dealer for service as soon as possible.

EMISSION CONTROL SYSTEMS

Noise Emission Control System

Do not modify the engine, intake or exhaust components, as doing so may affect compliance with state and local noise level requirements.

Spark Arrestor

Your Polaris vehicle has a spark arrestor that was tested and approved in accordance with the USDA Forest Service Standard 5100-1C. Federal law requires that this spark arrestor be installed and functional when the vehicle is operated on public lands.

Crankcase Emission Control System

This engine is equipped with a closed crankcase system. Blow-by gases are forced back to the combustion chamber by the intake system. The system does not allow the blow-by gases to enter the atmosphere.

Exhaust Emission Control System

The emissions from the exhaust of this vehicle are controlled by engine design, including factory-set fuel delivery and ignition. The engine and related components must be maintained at Polaris specifications to achieve optimal performance.

Adjustment to engine idle is the only adjustment Polaris recommends that the operator perform. Any other adjustments should be performed by an authorized Polaris dealer.

The emissions label (1) is located on the recoil cover.



Electromagnetic Interference

This spark ignition system complies with Canadian ICES-002.

Accessories

Auxiliary power outlets provide 12V power for operating accessories such as hand held spot lights. See your Polaris dealer.

Periodic Maintenance Chart

Careful periodic maintenance will help keep your vehicle in the safest, most reliable condition. Inspection, adjustment and lubrication of important components are explained in the periodic maintenance chart.

Inspect, clean, lubricate, adjust and replace parts as necessary. When inspection reveals the need for replacement parts, use genuine Polaris parts available from your Polaris dealer.

NOTE: Service and adjustments are critical. If you're not familiar with safe service and adjustment procedures, have a qualified dealer perform these operations.

Maintenance intervals in the following chart are based upon average riding conditions and an average vehicle speed of approximately 10 miles per hour. Vehicles subjected to severe use must be inspected and serviced more frequently.

Severe Use Definition

- Frequent immersion in mud, water or sand
- Racing or race-style high RPM use
- Prolonged low speed, heavy load operation
- Extended idle
- Short trip cold weather operation

Pay special attention to the oil level. A rise in oil level during cold weather can indicate contaminants collecting in the oil sump or crankcase. Change oil immediately if the oil level begins to rise. Monitor the oil level, and if it continues to rise, discontinue use and determine the cause or see your dealer.

Maintenance Chart Key

- ▶ Perform these procedures more frequently for vehicles subjected to severe use.
- E Emission Control System Service (California)
- Have an authorized Polaris dealer perform these services.

WARNING

Improperly performing the procedures marked with a **could** result in component failure and lead to serious injury or death. Have an authorized Polaris dealer perform these services.

MAINTENANCE AND LUBRICATION **Periodic Maintenance Chart**

Perform all services at whichever maintenance interval is reached first.

Item		Maintenance Interval (whichever comes first)			Remarks
		Hours	Calendar	Miles (Km)	
	Steering	-	Pre-Ride	+	Make adjustments as need- ed. See Pre-Ride Checklist
	Front suspension	-	Pre-Ride	-	on page 52.
	Rear suspension	-	Pre-Ride	-	
	Tires	-	Pre-Ride	-	
	Brake fluid level	-	Pre-Ride	-	
•	Brake lever travel	-	Pre-Ride	-	
	Brake systems	-	Pre-Ride	-	
	Wheels/fasteners	-	Pre-Ride	-	
	Frame fasteners	-	Pre-Ride	-	
≜ E	Engine oil level	-	Pre-Ride	-]
≜ E	Air filter, pre-filter	-	Daily	-	Inspect; clean often
ΔE	Air box sediment tube	-	Daily	-	Drain deposits when visible
	Coolant (if applicable)	1	Daily	1	Check level daily, change coolant every 2 years
	Headlamp/tail lamp	-	Daily	1	Check operation; apply dielectric grease if replacing
ΔE	Air filter, main element	-	Weekly	-	Inspect; replace as needed
	Recoil housing	-	Weekly	-	Drain water as needed, check often if operating in wet conditions
	Brake pad wear	10 H	Monthly	60 (100)	Inspect periodically
	Battery	20 H	Monthly	125 (200)	Check terminals; clean; test
•	Front gearcase oil (if equipped)	25 H	Monthly	155 (250)	Inspect level; change yearly
•	Middle gearcase oil (if equipped)	25 H	Monthly	155 (250)	Inspect level; change yearly
•	Rear gearcase oil (if equipped)	25 H	Monthly	155 (250)	Inspect level; change yearly
	Transmission oil	25 H	Monthly	155 (250)	Inspect level; change yearly

- Perform these procedures more often for vehicles subjected to severe use.
 E Emission Control System Service (California)
- Have an authorized Polaris dealer perform these services.

MAINTENANCE AND LUBRICATION Periodic Maintenance Chart

Item		Maintenance Interval (whichever comes first)			Remarks
		Hours	Calendar	Miles (Km)	
▶E	Engine breather filter (if equipped)	25 H	Monthly	155 (250)	Inspect; replace if necessary
ΔE	Engine oil change (break-in)	25 H	1 M	155 (250)	Perform a break-in oil change at one month
•	General lubrication	50 H	3 M	310 (500)	Lubricate all fittings, pivots, cables, etc.
	Shift Linkage	50 H	6 M	310 (500)	Inspect, lubricate, adjust
	Steering	50 H	6 M	310 (500)	Lubricate
•	Front suspension	50 H	6 M	310 (500)	Lubricate
•	Rear suspension	50 H	6 M	310 (500)	Lubricate
	Carburetor float bowl	50 H	6 M	310 (500)	Drain bowl periodically and prior to storage
■ E	Throttle Cable/ ETC Switch	50 H	6 M	310 (500)	Inspect; adjust; lubricate; replace if necessary
■ E	Choke cable	50 H	6 M	310 (500)	Inspect; adjust; lubricate; replace if necessary
Ε	Carburetor air intake ducts/ flange	50 H	6 M	310 (500)	Inspect ducts for proper sealing/air leaks
	Drive belt	50 H	6 M	310 (500)	Inspect; adjust; replace as needed
	Cooling system (if applicable)	50 H	6 M	310 (500)	Inspect coolant strength seasonally; pressure test system yearly
≜ E	Engine oil change	100 H	6 M	620 (1000)	Perform a break-in oil change at 25 hours/one month
≜ E	Oil filter change	100 H	6 M	620 (1000)	Replace with oil change
ΔE	Oil tank vent hose	100 H	12 M	620 (1000)	Inspect routing, condition
■ E	Valve clearance	100 H	12 M	620 (1000)	Inspect; adjust

Perform these procedures more often for vehicles subjected to severe use.
 E Emission Control System Service (California)

[■] Have an authorized Polaris dealer perform these services.

MAINTENANCE AND LUBRICATION **Periodic Maintenance Chart**

Item		Maintenance Interval (whichever comes first)			Remarks
		Hours	Calendar	Miles (Km)	
E	Fuel system	100 H	12 M	620 (1000)	Check for leaks at tank cap, lines, fuel valve, filter, pump, carburetor; replace lines every two years
■ E	Fuel filter	100 H	12 M	620 (1000)	Replace yearly
•	Radiator (if applicable)	100 H	12 M	620 (1000)	Inspect; clean external surfaces
•	Cooling hoses (if applicable)	100 H	12 M	620 (1000)	Inspect for leaks
•	Engine mounts	100 H	12 M	620 (1000)	Inspect
	Exhaust muffler/ pipe	100 H	12 M	620 (1000)	Inspect
■ E	Spark plug	100 H	12 M	620 (1000)	Inspect; replace as needed
■ E	Ignition Timing	100 H	12 M	620 (1000)	Inspect
•	Wiring	100 H	12 M	620 (1000)	Inspect for wear, routing, security; apply dielectric grease to connectors subjected to water, mud, etc.
	Clutches (drive and driven)	100 H	12 M	620 (1000)	Inspect; clean; replace worn parts
	Front wheel bearings	100 H	12 M	1000 (1600)	Inspect; replace as needed
	Brake fluid	200 H	24 M	1240 (2000)	Change every two years
	Spark arrestor	300 H	36 M	1860 (3000)	Clean out
Е	Idle speed	-			Adjust as needed
	Toe adjustment	-			Inspect periodically; adjust when parts are replaced
▲	Auxiliary brake	-			Inspect daily; adjust as needed
	Headlight aim	-			Adjust as needed

Perform these procedures more often for vehicles subjected to severe use.
 E Emission Control System Service (California)

[■] Have an authorized Polaris dealer perform these services.

Lubrication Recommendations

Check and lubricate all components at the intervals outlined in the Periodic Maintenance Chart beginning on page 73. Items not listed in the chart should be lubricated at the General Lubrication interval.

Lubrication Chart Key

- ▶ More often under severe use, such as wet or dusty conditions
- ★ Polaris Premium All Season Grease or grease conforming to NLG No. 2, such as Conoco Superlube M or Mobilegrease Special
- Use Polaris Premium U-Joint Lube every 500 miles, before long periods of storage, or after pressure washing or submerging

Item	Lube	Method
Engine	Polaris Premium 4 Synthetic 0W40	Add to proper level on dipstick.
Brakes	DOT 3 fluid only	Maintain level between fill lines. See page 37.
Transmission	Premium AGL Synthetic Gearcase Lube	See Page 85.
Front Gearcase	Polaris Premium Demand Drive Hub Fluid	See Page 86.
Rear Gearcase	Premium ATV Angle Drive Fluid	See page 87.
Front Prop Shaft U-joints	●Grease	Grease fittings.
Front Prop Shaft Yoke		Grease fittings (3 pumps maximum)
Ball Joint	▶★Grease	Locate fitting on back side of struts and grease with grease gun.

Periodic Maintenance Record

Use the following chart to record periodic maintenance.

Maintenance Interval Performed	Servicing Date	Servicing Dealer or Person	Remarks

Lubrication Recommendations Engine Oil

Always check and change the engine oil at the intervals outlined in the Periodic Maintenance Chart beginning on page 73. Always change the oil filter whenever changing oil.

Premium 4 Synthetic Oil

Polaris Premium 4 All Season Synthetic engine oil has been specially formulated for use in Polaris 4-cycle engines. It's a fully synthetic, high performance, multi-viscosity oil designed to provide the ultimate in lubrication performance and protection. See page 119 for the part numbers of Polaris products.

Premium 4 possesses unsurpassed film strength over the widest possible temperature range. It resists viscosity and frictional breakdown in ambient temperatures from -40° F. to 120° F. Its exceptional frictional properties result in more efficient operation, more power output and lower fuel consumption.

Although Polaris Premium 4 is the only oil recommended for use in this engine, use of any API certified "SH" oil is allowable as long as it's 0W-40. Oil may need to be changed more frequently if Polaris Premium 4 is not used. Follow the manufacturer's recommendations for ambient temperature operation.

CAUTION


Mixing brands or using a non-recommended oil may cause serious engine damage. We recommend the use of Polaris Premium 4 All Season synthetic oil or API certified "SH" oil, 0W-40. Never substitute or mix oil brands. Use only 0W-40.

Lubrication Recommendations Engine Oil


Oil Check (ATP 500)

The oil tank is located on the left side of the vehicle.

- 1. Position the ATV on a level surface.
- 2. Start the engine and let it idle for 20-30 seconds. Stop the engine.
- 3. Remove the dipstick (1) and wipe it dry with a clean cloth.
- 4. Screw the dipstick completely in.



 Remove the dipstick and read the oil level. Maintain the oil level in the normal operating range (2). Do not overfill.



Oil and Filter Change (ATP 500)

CAUTION

If the ATV is left without oil in the system for extended periods, the oil pump may lose its prime, which could result in engine damage. Always replace the oil and filter within a few hours of draining the oil. Do not allow the vehicle to be without oil overnight.

- 1. Obtain the correct oil filter and an adequate supply of oil so the oil and filter change can be completed without interruption.
- 2. Position the vehicle on a level surface. Clean the area around the drain plug at the bottom of the oil tank and the bottom of the engine.
- 3. Run the engine for two to three minutes, then turn it off.

A CAUTION

Hot oil can cause serious burns to skin. Do not allow hot oil to come into contact with skin.

Lubrication Recommendations Engine Oil

Oil and Filter Change (ATP 500)


- 4. Place a drain pan beneath the oil tank and remove the drain plug (1). Allow the oil to drain completely.
- 5. Install a new sealing washer (2) on the oil drain plug.


NOTE: The sealing surfaces on the drain plug and the oil tank should be clean and free of burrs, nicks or scratches.

- 6. Reinstall the drain plug and torque to 14-17 ft. lbs. (19-23 Nm).
- 7. Disconnect the lower oil delivery hose and remove the screen fitting (3) from the oil tank. Clean and reinstall the fitting, torquing to 25 ft. lbs. (34 Nm). Reattach the oil line.

NOTE: The fitting threads must be sealed with Loctite™ PST 505 or PTFE seal tape. The fitting must also line up with the mark (4) on the rear side of the oil

- 8. Place shop towels beneath the oil filter. Using an oil filter wrench, turn the filter (1) counterclockwise and remove.
- 9. Lubricate the gasket on the new filter with a film of new engine oil. Check to make sure the gasket is in good condition.
 Also make sure the gasket from the old filter is not still on the engine.
- 10. Install the new filter and tighten by hand 1/2 to 3/4 turn after gasket contacts the engine.





Lubrication Recommendations Engine Oil

Oil and Filter Change (ATP 500)

11. Approximately one cup of engine oil will remain in the crankcase. To drain, remove the drain plug on the lower right side of the crankcase.

NOTE: The sealing surfaces on the drain plug and crankcase should be clean and free of burrs, nicks or scratches.


12. After draining, reinstall the drain plug.

13. Remove the dipstick (2) and add two quarts (1.9 l) of Polaris Premium 4 synthetic oil. Reinstall the dipstick.

NOTE: If the sump is not drained, add about 1 3/4 quarts

(1.6 l) initially.

14. Place the gear selector in park and set the parking brake.




- 16. Re-check the oil level on the dipstick and add oil as necessary to bring the level to the upper (full) mark on the dipstick.
- 17. Dispose of used filter and oil properly.

Oil Pump Priming


This priming procedure must be performed whenever the oil hose connection between the oil tank and pump inlet has been disconnected.

1. Clamp or pinch off the vent line (1) approximately 2" (5 cm) from the oil tank (2), between the end of the oil tank vent fitting and the vent line's pressure relief slit (3).



3. Remove the vent line clamp. If the line is bled properly, you should hear a rush of air, indicating that the line is properly primed and ready for operation

properly primed and ready for operation. If you do not hear air, the line has not bled, and you'll need to repeat the priming procedure.




Lubrication Recommendations Engine Oil

Oil Check (ATP 330)

The oil fill is located on the left side of the engine (1). Maintain the oil level in the safe operating range (2). Do not overfill.

- 1. Position the machine on a level surface.
- Start the engine and let it idle for 20-30 seconds. Stop the engine.
- 3. Remove the dipstick and wipe it dry with a clean cloth.
- 4. Screw the dipstick completely in.
- 5. Remove the dipstick and read the oil level. Add the recommended oil as needed.



2

Oil and Filter Change (ATP 330)

CAUTION

If the ATV is left without oil in the system for extended periods, the oil pump may lose its prime, which could result in engine damage. Always replace the oil and filter within a few hours of draining the oil. Do not allow the vehicle to be without oil overnight.

- Obtain the correct oil filter and an adequate supply of oil so the oil and filter change can be completed without interruption.
- 2. Position the vehicle on a level surface.
- 3. Clean the area around the drain plug on the bottom of the engine crankcase.
- 4. Run the engine for two to three minutes until warm. Stop the engine.

CAUTION

Contact with hot oil may result in serious burns. Do not allow hot oil to come into contact with skin.

- 5. Place a drain pan beneath the engine crankcase and remove the drain plug.
- 6. Allow the oil to drain completely.
- Install a new sealing washer on the drain plug. 7.

The sealing surfaces on the drain plug and crankcase should NOTE: be clean and free of burrs, nicks or scratches.

Lubrication Recommendations Engine Oil


Oil and Filter Change (ATP 330)

- 8. Reinstall the drain plug. Torque to 14 ft. lbs. (19 Nm).
- Place shop towels beneath the oil filter. Using an oil filter wrench, turn the filter counterclockwise to remove.
- 10. Using a clean, dry cloth, clean the filter sealing surface on the crankcase.
- 11. Lubricate the gasket on the new filter with a film of engine oil. Check to make sure the gasket is in good condition.
- 12. Install the new filter and turn by hand until the filter gasket contacts the sealing surface, then turn and additional 1/2 turn.
- 13. Remove the dipstick and fill the sump with 2 quarts (1.91) of Polaris Premium 4 synthetic oil.
- 14. Place the gear selector in park and set the parking brake.
- 15. Start the engine and let it idle for one to two minutes. Stop the engine and inspect for leaks.
- 16. Recheck the oil level and add oil as necessary to bring the level to the upper mark on the dipstick.
- 17. Dispose of used filter and oil properly.

Lubrication Recommendations

Transmission Oil

Always check and change the transmission oil at the intervals outlined in the Periodic Maintenance Chart beginning on page 73. Maintain the oil level 1 5/8" from the top of the fill hole. We recommend the use of Premium AGL Synthetic Gearcase Lubricant. See page 119 for the part numbers of Polaris products.



Oil Check


The transmission fill plug (1) is located on the right side of the machine, behind the footwell.

- 1. Position the ATV on a level surface.
- 2. Remove the fill plug.
- 3. Check the oil level.
- 4. Add the recommended oil as needed.
- 5. Reinstall the fill plug. Torque to 14 ft. lbs. (19 Nm).

Oil Change

The transmission drain plug (2) is located on the bottom left-hand side of the machine, behind the footwell.

- 1. Remove the fill plug.
- Remove the transmission drain plug and drain the oil into an appropriate container. Discard used oil properly.
- 3. Clean and reinstall the drain plug. Torque to 14 ft. lbs. (19 Nm).
- 4. Add 13.5 oz. (400 ml) of the recommended oil.
- 5. Reinstall the fill plug. Torque to 14 ft. lbs. (19 Nm).
- Check for leaks.



Lubrication Recommendations

Front Gearcase Oil


Always check and change the front gearcase oil at the intervals outlined in the Periodic Maintenance Chart beginning on page 73. Maintain the oil level 3/4" below the fill plug opening. We recommend the use of Polaris Premium Demand Drive Hub Fluid. See page 119 for the part numbers of Polaris products.

Oil Check

- 1. Position the vehicle on a level surface.
- 2. Remove the fill plug (1).
- 3. View the oil level and add the recommended oil as needed.
- 4. Reinstall the fill plug. Torque to 8-10 ft. lbs. (11-14 Nm).

Oil Change

- 1. Position the vehicle on a level surface.
- 2. Remove the fill plug.
- 3. Place a drain pan beneath the gearcase. Remove the gearcase drain plug (2) and drain the oil.
- 4. Clean and reinstall the drain plug. Torque to 11 ft. lbs. (15 Nm).
- 5. Add 5 oz. (148 ml) of the recommended gearcase oil.
- 6. Reinstall the fill plug. Torque to 8-10 ft. lbs. (11-14 Nm).
- 7. Check for leaks.



Lubrication Recommendations

Rear Gearcase Oil


Always check and change the rear gearcase oil at the intervals outlined in the Periodic Maintenance Chart beginning on page 73. Maintain the oil level at the bottom of the fill hole. We recommend the use of Polaris ATV Angle Drive Fluid. See page 119 for the part numbers of Polaris products.


Oil Check

- 1. Position the ATV on a level surface.
- 2. Remove the fill plug (1).
- 3. View the oil level through the fill hole.
- 4. Add the recommended oil as needed.
- 5. Reinstall the fill plug. Torque to 40 ft. lbs. (54 Nm).



- 1. Place a drain pan under the drain plug (2).
- 2. Remove the drain plug.
- 3. Drain the oil and dispose of properly.
- 4. Clean the drain plug and inspect the o-ring. Install a new o-ring if signs of tearing or fretting exist.
- 5. Reinstall the drain plug. Torque to 40 in. lbs. (4.5 Nm).
- 6. Remove the fill plug.
- 7. Add 16 oz. (473 ml) of the recommended oil.
- 8. Clean the fill plug and inspect the o-ring. Install a new o-ring if it's worn or damaged.
- 9. Reinstall the fill plug. Torque to 40 ft. lbs. (54 Nm).
- 10. Check for leaks.





MAINTENANCE AND LUBRICATION Engine Cooling System Oil Cooler (ATP 330)

The oil cooling system requires little maintenance other than to make sure the cooler is kept free of mud and debris. Change the engine oil as recommended in the maintenance schedule.

Cooling System Operation (ATP 500)

The engine coolant level is controlled or maintained by the recovery system. The recovery system components are the recovery bottle, radiator filler neck, radiator pressure cap and connecting hose.

As coolant operating temperature increases, the expanding (heated) excess coolant is forced out of the radiator, past the pressure cap, and into the recovery bottle. As engine coolant temperature decreases, the contracting (cooled) coolant is drawn back up from the tank, past the pressure cap, and into the radiator.

NOTE:

Some coolant level drop on new machines is normal, as the system is purging itself of trapped air. Observe coolant levels and maintain as recommended by adding coolant to the recovery bottle.

Coolant (ATP 500)

To ensure that the coolant maintains its ability to protect the engine, we recommend that the system be completely drained every two years and a fresh mixture of antifreeze and water added. Polaris recommends the use of Polaris Premium 60/40 anti-freeze/coolant or a 50/50 mixture of high quality aluminum compatible anti-freeze/coolant and distilled water. Polaris Premium 60/40 is already premixed and ready to use. Do not dilute with water. See page 119 for the part numbers of Polaris products.


NOTE: Always follow the manufacturer's mixing recommendations for the freeze protection required in your area.

Any time the cooling system has been drained for maintenance or repair, replace the coolant. If the recovery bottle has run dry, the level in the radiator should be inspected. Add coolant as needed.

Engine Cooling System Coolant Level (ATP 500)

The recovery bottle (1) is located on the left side of the machine. To access the recovery bottle, remove the left side panel. See page 97.

Maintain the coolant level between the minimum and maximum marks on the bottle (when the fluid is cool).




▲ WARNING

Escaping steam can cause severe burns. Never remove the pressure cap while the engine is warm or hot. Always allow the engine to cool before removing the pressure cap.

Radiator Coolant Level (ATP 500)

Checking the radiator coolant level is required only if the cooling system has been drained for maintenance and/or repair. However, if the recovery bottle has run dry, the level in the radiator should also be inspected. Add coolant if necessary.

Using the tool provided, remove the four screws securing the front compartment (1). Remove the front cover (2) by placing your fingers under the front of the cover and pulling upward.



- Remove the pressure cap.
- Using a funnel, slowly add coolant as necessary through the radiator filler neck.
- Replace the pressure cap and secure the front cover.

NOTE: Use of a non-standard pressure cap will not allow the recovery system to function properly. Contact your dealer for the correct replacement part.

Adjustments

Brakes

The front brakes are hydraulic disc brakes, activated by moving the brake lever toward the handlebar. These brakes are self-adjusting.

WARNING

Never store or use a partial bottle of brake fluid. Brake fluid is hygroscopic, meaning it rapidly absorbs moisture from the air. The moisture causes the boiling temperature of the brake fluid to drop, which can lead to early brake fade and the possibility of accident or severe injury. After opening a bottle of brake fluid, always discard any unused portion.

The following checks are recommended to keep the brake system in good operating condition. Check more often if brakes are used heavily under normal operation.

1. Always keep brake fluid at an adequate level (see page 37).

NOTE:


Under normal operation, the diaphragm extends into the reservoir as fluid level drops. If the fluid level is low and the diaphragm is not extended, a leak is likely and the diaphragm should be replaced. Always fill the reservoir as needed whenever the cover is loosened or removed to ensure proper diaphragm operation. Use Polaris DOT 3 brake fluid. Do not overfill.

WARNING

An over-full master cylinder may cause brake drag or brake lock-up, which could result in serious injury or death. Maintain brake fluid at the recommended level. Do not overfill.

- 2. Check the brake system for fluid leaks.
- 3. Check the brakes for excessive travel or spongy feel.
- 4. Check the friction pads for wear, damage and looseness.
- 5. Check the security and surface condition of the disc.

NOTE: Change the brake pads when they're worn to 3/64" (.1 cm).



Adjustments Auxiliary Brake

The auxiliary brake is a hydraulic disc brake. The rear brake system is self-adjusting and requires no maintenance other than periodic checks of the pads for wear.

Change the brake pads when they're worn to 3/64" (.1 cm).

Inspect the brake disc spline and pad wear surface for excessive wear.

Your vehicle's auxiliary brake system is intended to be used as a backup for the main brake system. Should the main system fail, the rear brake can be activated by depressing the foot pedal on the inside of the right footrest.

NOTE: Since the auxiliary brake is a rear brake only, it will not be as effective for braking as the all-wheel single lever system.

MAINTENANCE AND LUBRICATION Adjustments

A WARNING

Severe injury or death can result from improper toe alignment and adjustment. Do not attempt to adjust tie rod alignment. All tie rod adjustments should be performed by an authorized Polaris dealer.

Toe Alignment


Use the following procedure to check the toe alignment of the vehicle. The recommended toe alignment is 1/8'' to 1/4'' toe out.

1. Set the handlebars in a straight-ahead position.

NOTE: The steering frog can be used as an indicator of whether the handlebars are straight. The frog should always point straight back from the steering post.

- 2. Place stands (1) in front of the vehicle, perpendicular to the rear tires. See illustration.
- 3. Tie an elastic string around the stands, making sure the string just touches the side surface of the rear tires on each side of the vehicle and goes around the stands in front of the vehicle (2).
- 4. Measure the distance from the string to the rim at the front and rear of the front rim (3). Rear measurement should be 1/16" 1/8" (.2 to .3 cm) more than the front measurement.

NOTE: If you discover improper alignment, see your Polaris dealer for service.



Adjustments

Steering Assembly

The steering assembly of the ATV should be checked periodically for loose nuts and bolts. If loose nuts and bolts are found, see your Polaris dealer for service before operating the vehicle.

Camber and Caster


The camber and caster are non-adjustable.

Rear Spring

The rear shock absorber spring is adjusted by rotating the adjuster (1) either clockwise or counterclockwise to increase or decrease spring tension.

NOTE: Accessory springs are available

through your Polaris dealer.



Adjustments


Handlebars

If desired, the handlebars can be adjusted for rider preference.

WARNING

Improper adjustment of the handlebars or incorrect torquing of the adjuster block tightening bolts can cause limited steering or loosening of the handlebars, resulting in loss of control and possible serious personal injury or death. Follow the adjustment procedures exactly, or see your Polaris dealer for service.

- 1. Remove the instrument panel and locate the handlebar bolts (1).
- 2. Loosen the four bolts and adjust the handlebar to the desired height. Be sure the handlebars do not contact the gas tank or any other part of the machine when turned fully to the left or right.



3. Torque the front two bolts to 10-12 ft. lbs. (14-17 Nm), then torque the rear two bolts. A gap of up to 1/8" will remain at the rear bolts.

Adjustments


Carburetor

Your Polaris ATV is calibrated at the factory for optimal performance at altitudes ranging from zero to 6,000 feet (1800 m) and temperatures of +40 degrees F. (4 degrees C.) or higher. Above 6000 feet (1800 m) the engine air/fuel mixture becomes overly rich and the engine loses approximately 3% of its power for each 1000-foot (304.8 m) increase in elevation. Although this power cannot be regained, adjustments to the carburetor and drive system can be made to allow more efficient operation. Optional jets, available from your Polaris dealer, are required for operation above 6,000 feet and temperatures below +40 degrees F. (4 degrees C.)

NOTE: Continuous operation of the engine without proper jetting when required can cause poor performance, overheating or engine damage. See your Polaris dealer for more information about jetting the ATV for conditions in your area.

If the engine idle speed is not satisfactory, and all other conditions are favorable, the carburetor can be adjusted.

- Warm up the engine by running the vehicle for approximately five minutes.
- 2. Place the transmission in gear with the parking brake applied.
- 3. Adjust the carburetor idle screw (1) either in or out until the desired idle RPM is reached. Turning the screw in (clockwise) will raise RPM. Turning the screw out (counterclockwise) will lower RPM.



Adjustments


Throttle Cable Freeplay

Throttle cable freeplay is adjusted at the handlebar.

- 1. Slide the boots (1) off the inline cable adjuster sleeve (2). Loosen the adjuster locknut (3).
- 2. Turn the adjuster until 1/16" to 1/8" (.16-.32 cm) freeplay is achieved at the thumb lever.

NOTE: While adjusting freeplay, be sure to flip the throttle lever back and forth.


3. Tighten the locknut and slide the boots over the cable adjuster until they touch at the midpoint of the adjuster.





Adjustments Side Panel Removal

NOTE: Side panel removal may be difficult until the locking tabs and receivers have been snapped and unsnapped a few times.

- 1. Remove the seat.
- 2. Grasp the rear of the side panel near the rear cab. With a quick and firm motion, pull the panel forward and outward to disengage the two rear tabs.
- 3. Place your hand on top of the side panel behind the fuel tank. With a quick and firm motion, push down on the side panel to disengage the top rear two tabs. Then pull up on the side panel to disengage the front upper and lower tabs.
- 4. To reinstall the side panel, align the panel tabs with the slots on the front cab. Push the panel upward and forward until the tabs lock. Bend the rear of the side panel and insert the two tabs into the rear cab.







MAINTENANCE AND LUBRICATION Adjustments

WARNING

Operating your ATV with worn tires, improperly inflated tires, non-standard tires or improperly installed tires will affect vehicle handling and could cause an accident resulting in serious injury or death.

Maintain proper tire pressure as described on the decal on your ATV and in the specifications section of the owner's manual beginning on page 124.

Always use original equipment size and type when replacing tires.

Make sure the wheels are installed properly.

Always replace tires when the tread depth measures 1/8" (.3 cm) or less.

Wheel Removal

- 1. Stop the engine, place the transmission in park and lock the parking brake.
- 2. Loosen the wheel nuts slightly.
- 3. Elevate the side of the vehicle by placing a suitable stand under the footrest frame.
- 4. Remove the wheel nuts and remove the wheel.


Adjustments


A WARNING

Improperly installed wheels can adversely affect tire wear and vehicle handling, which can result in serious injury or death. Always ensure that all nuts are torqued to specification. Do not service axle nuts that have a cotter pin installed. See your Polaris dealer.

Wheel Installation

- Place the transmission in park and lock the parking brake.
- 2. Place the wheel on the wheel hub with the valve stem toward the outside and rotation arrows on the tire pointing toward forward rotation.






5. Torque the nuts to specification.



Check the wheel nut torques occasionally and when they've been loosened for maintenance service.

Location	Specification	
Front Wheel Nuts	27 ft. lbs. (37 Nm)	
Rear Wheel Nuts	27 ft. lbs. (37 Nm)	



MAINTENANCE AND LUBRICATION Adjustments

Front Wheel Hub Tightening

Front wheel bearing tightness and spindle nut retention are critical component operations. All service must be performed by your authorized Polaris dealer.


Tire Tread Depth

Always replace tires when tread depth is worn to 1/8" (.3 cm) or less. See illustration.



A WARNING

Operating the vehicle with worn tires will increase the possibility of skidding. which could lead to loss of control and serious injury or death. Always replace tires when the tread depth measures 1/8" (.3 cm) or less.





A WARNING

Use of non-standard size or type of tires or improper tire inflation may adversely affect vehicle maneuverability and cause loss of control resulting in serious injury or death. Maintain proper tire pressure as outlined in this owner's manual. When replacing a tire always use original equipment size and type.

Filter Systems

Air Filter

- Remove the seat, release the clips, and remove the air box cover.
- 2. Loosen the clamp and remove the filter.
- 3. Remove the fabric type pre-filter (1) from the main filter (2). Wash the pre-filter in soapy water, then rinse and let dry.
- 4. Reinstall the pre-filter over the main filter. (Replace the main filter if necessary.)
- 5. Reinstall the filter into the air box and tighten the clamp. Do not over tighten the clamp, as filter damage could occur.



CAUTION


Operation of your vehicle without a breather filter can cause engine damage. Always reinstall the breather filter after removing for service.

1. Remove the clamps and pull the filter (1) out of the hoses.

NOTE: It's not necessary to remove the lower hose from the engine.

- Inspect the filter for debris. Blow gently through the filter in the direction of the arrow to check for clogging. Replace if needed.
- 3. Check the hoses for cracks, deterioration, abrasion, or leaks. Replace as needed.
- 4. Reinstall the filter and secure the clamps.

NOTE: The filter is effective with the arrow pointing in either direction.



MAINTENANCE AND LUBRICATION Lights

When servicing a halogen lamp, don't touch the lamp with bare fingers. Oil from your skin leaves a residue, causing a hot spot that will shorten the life of the lamp.

WARNING

Poor lighting while driving can result in severe injury or death. Headlight and taillight lenses become dirty during normal operation. Wash the headlights frequently to maintain lighting quality.

Hot components can cause serious burns to skin. Do not service the headlamps until they've cooled sufficiently.


Headlight Lamp Replacement (ATP 500)

- 1. Remove the three screws on the headlight pod.
- 2. Using a small flat-blade screwdriver, push in on the lock tabs through the two small openings at the front of the headlight pod.
- 3. Lift the pod slightly while depressing the tabs.
- 4. Lift the pod cover and disconnect the speedometer harnesses from the speedometer. Unplug the indicator light harness and remove the pod cover.
- 5. Unplug the headlamp from the wiring harness. Be sure to pull on the connector, not on the wiring.
- 6. Grasp the bulb housing and turn counterclockwise to remove lamp.
- 7. Apply dielectric grease to the light bulb socket before installing the new bulb.
- 8. Reverse the previous steps to replace the lamp and reassemble the pod.

Lights

Lower Headlight Lamp Replacement

- 1. Turn the back of the headlight harness in a counter-clockwise direction to loosen (A).
- 2. Pull the harness assembly out from the headlight assembly.
- 3. Remove the headlamp and replace with a new headlamp.



Lower Headlight Adjustment

- 1. Loosen the nuts(C) that secure the lower headlamps. Adjust the headlamps as needed.
- 2. Tighten the nuts on the headlamps after adjustment is made.

Taillight/Brakelight Lamp Replacement

If the taillight/brakelight does not work, the lamp may need to be replaced.

- 1. Remove the two screws securing the lens assembly.
- 2. Pivot the assembly outward.
- 3. Turn the housing clockwise and remove the bulb.
- 4. Apply dielectric grease to the socket and install a new bulb.
- 5. Reinstall the taillight assembly.


MAINTENANCE AND LUBRICATION Lights

Headlight Housing Replacement

- 1. Remove the three screws on the headlight pod.
- 2. Using a small flat-blade screwdriver, push in on the lock tabs through the two small openings at the front of the headlight pod. Lift the pod lightly while depressing the tabs.
- 3. Lift the pod cover. Disconnect the speedometer harnesses from the speedometer. Unplug the indicator light harness and remove the pod cover.
- 4. Unplug the headlamp from the wiring harness.
- 5. Remove the o-ring (1) from the headlight pivot pins.
- 6. Pull the headlight housing up to release from the locking tabs.
- 7. Lift the adjusting knob up to remove from the locking tabs.
- 8. Carefully pull the assembly up and out of pod.
- 9. Reverse the steps to install the new housing and reassemble the pod.

NOTE: The distance from the headlamp parting line to the end of the adjustment knob stop is 5 1/8" (13 cm). See illustration.

10. Adjust the headlight aim by turning the adjusting knob.



Lights


High Beam Adjustment

The headlight beam can be adjusted to any position desired by turning the adjusting knob on the bottom right side of the headlight pod.

- 1. Position the vehicle on a level surface with the headlight approximately 25 ft. (7.6 m.) from a wall.
- 2. Remove the two screws on the lower front corners of the headlight pod.
- 3. Using a small flat-blade screwdriver, push in on the lock tab through the two small openings at the front of the headlight pod.
- 4. Lift the pod slightly while depressing the tabs.
- 5. Remove the screw in the back of the headlight pod.
- 6. Measure the distance from the floor to the center of the headlight and make a mark on the wall at the same height.
- 7. Start the engine and turn the headlight switch to high beam.
- 8. Observe the headlight aim on the wall. The most intense part of the headlight beam should be aimed two inches (5.1 cm) below the mark placed on the wall.

NOTE: Include rider weight on the seat when measuring.

- 9. Adjust the beam to the desired position by turning the adjustment knob either clockwise or counterclockwise.
- 10. Reinstall the pod.



MAINTENANCE AND LUBRICATION Spark Plugs

- Use the recommended spark plugs for your model (see SPECIFICATIONS beginning on page 124).
- Make sure the electrode gap meets specifications for your model.
- Torque spark plugs to 14 ft. lbs. (19 Nm).

CAUTION

Using non-recommended spark plugs can result in serious engine damage. Always use Polaris-recommended spark plugs.

Spark plug condition is indicative of engine operation. The spark plug firing end condition should be read after the engine has been warmed up and the vehicle has been driven at higher speeds. Immediately check the spark plug for correct color.

WARNING

A hot exhaust system and engine can cause serious burns. Wear protective gloves when removing a spark plug for inspection.

1. Normal

The normal insulator tip is gray, tan or light brown. There will be few combustion deposits. The electrodes are not burned or eroded. This indicates the proper type and heat range for the engine and the service.

NOTE: The tip should not be white. A white insulator tip indicates overheating, caused by use of an improper spark plug or incorrect carburetion adjustments.

2. Wet Fouled

The wet fouled insulator tip is black. A damp oil film covers the firing end. There may be a carbon layer over the entire nose. Generally, the electrodes are not worn. General causes of fouling are excessive oil, use of non-recommended injection oil, improper use of the choke, or incorrect carburetion adjustments.

Spark Plug Removal and Replacement

- 1. Remove the spark plug cap.
- 2. Using the special wrench provided in the tool pouch, rotate the spark plug counterclockwise to remove.
- 3. Reverse the procedure for spark plug installation. Torque to 14 ft. lbs. (19 Nm).

Vehicle Immersion


CAUTION

If your vehicle becomes immersed, major engine damage can result if the machine is not thoroughly inspected. Take the vehicle to your dealer before starting the engine.

If it's impossible to take your ATV to a dealer before starting it, follow the steps outlined below.

- 1. Move the ATV to dry land or at the very least, to water below the foot rests.
- 2. Turn the fuel valve off.
- 3. Remove the spark plug.
- 4. Check the air box and drain if water is present.
- 5. Loosen the carburetor drain screw (1).
- 6. Turn the engine over several times using the electric start.
- 7. Dry the spark plug and reinstall, or replace it with a new plug.
- 8. Tighten the carburetor drain screw.
- 9. Turn the fuel valve on.
- 10. Attempt to start the engine. If necessary, repeat the drying procedure.
- 11. Take the ATV to your dealer for service as soon as possible, whether you succeed in starting it or not.

NOTE: If water has been ingested into the PVT, follow the procedure on page 71 for drying out the PVT.



MAINTENANCE AND LUBRICATION Spark Arrestor


WARNING

Failure to heed the following warnings while servicing the spark arrestor could result in serious injury or death.

Do not perform service on the spark arrestor while the system is hot. Exhaust system temperatures can reach 1000° F. Allow components to cool sufficiently before proceeding.

Remove any combustible materials from the area. Wear eye protection and leather work gloves. Do not stand behind or in front of the vehicle while purging. Never run the engine in an enclosed area. Exhaust contains poisonous carbon monoxide gas. Never go under the vehicle while it's inclined.

- Remove the arrestor clean-out plug(s) (1) from the bottom of the muffler.
- 2. Place the transmission in PARK and start the engine.
- 3. Purge carbon from the system by momentarily revving the engine several times.



- 4. If carbon is expelled, cover or plug the exhaust outlet (2) and rap on the pipe around the cleanout plug while revving the engine several more times.
- 5. If particles are still suspected to be in the muffler, back the vehicle onto an incline so the rear of the vehicle is one foot higher than the front. Set the parking brake and block the wheels. Make sure the vehicle is in PARK and repeat steps 3 and 4 until no more particles are expelled when the engine is revved.
- 6. Stop the engine and allow the arrestor to cool. Reinstall the arrestor plug and remove the outlet cover or plug.


Recoil Housing

To prevent possible engine damage, always drain the recoil housing (1) after operating the ATV in very wet conditions. This should also be done before storing the ATV.

NOTE: Water will enter the recoil

housing if the starter handle is disengaged from the rope guide


when under water.



NOTE: Do not open the *crankcase* drain unless the engine has

ingested water. Some engine oil will be lost if the crankcase

drain is opened.



MAINTENANCE AND LUBRICATION Battery

WARNING

Improperly connecting or disconnecting battery cables can result in an explosion and cause serious injury or death. When removing the battery, always disconnect the negative (black) cable first. When reinstalling the battery, always connect the negative (black) cable last.

Battery Removal

- 1. Disconnect the battery hold-down strap and remove the battery cover.
- 2. Disconnect the black (negative) battery cable first.
- 3. Disconnect the red (positive) battery cable next.
- 4. Lift the battery out of the ATV.

Battery Installation

When installing a new battery, make sure it's fully charged prior to its initial use. Using a new battery that has not been fully charged can damage the battery and result in a shorter life. It can also hinder vehicle performance. Follow the battery charging instructions on page 111 before installing the battery.

- 1. Ensure that the battery is fully charged.
- 2. Set the battery in the battery holder.
- 3. Connect and tighten the red (positive) cable first.
- 4. Connect and tighten the black (negative) cable last.
- 5. Reinstall the battery cover and attach the hold-down strap.
- 6. Verify that cables are properly routed.

Battery

Battery Storage

Whenever the vehicle is not used for a period of three months or more, remove the battery from the vehicle, ensure that it's fully charged, and store it out of the sun in a cool, dry place. Check battery voltage each month during storage and recharge as needed to maintain a full charge.

NOTE: Battery charge can be maintained by using a Polaris Battery Tender™ charger (PN 2871076) or by charging about once a month to make up for normal self-discharge. Battery Tender™ can be left connected during the storage period, and will automatically charge the battery if the voltage drops below a pre-determined point.

Battery Charging

The following battery charging instructions apply only to the installation of a sealed battery. Read all instructions before proceeding with the installation of this battery.

The sealed battery is already filled with electrolyte and has been sealed and *fully charged* at the factory. *Do not ever* pry the sealing strip off or add any other fluid to this battery.

The single most important thing about maintaining a sealed battery is to keep it fully charged. Since the battery is sealed and the sealing strip cannot be removed, you must use a voltmeter or multimeter to measure DC voltage.

For a refresh charge, follow all instructions carefully.

- 1. Check the battery voltage with a voltmeter or multimeter. A fully charged battery will register 12.8 V or higher.
- 2. If the voltage is less than 12.8 volts, recharge the battery at 1.2 amps or less until thebattery voltage is 12.8 or greater.

NOTE: When using an automatic charger, refer to the charger manufacturer's instructions for recharging. When using a constant current charger, use the following guidelines for recharging.

WARNING

An overheated battery may explode, causing severe injury or death. Always watch charging times carefully. Stop charging if the battery becomes very warm to the touch. Allow it to cool before resuming charging.

MAINTENANCE AND LUBRICATION Battery

Battery Charging

NOTE: Always verify battery condition before and 1-2 hours after the end of charging.

State of Charge	Voltage	Action	Charge Time* (Using constant current charger @ standard amps specified on top of battery)
100%	12.8-13.0 volts	None, check at 3 mos. from date of manufacture	None required
75%-100%	12.5-12.8 volts	May need slight charge, if no charge given, check in 3 months	3-6 hours
50%-75%	12.0-12.5 volts	Needs Charge	5-11 hours
25%-50%	11.5-12.0 volts	Needs Charge	At least 13 hours, verify state of charge
0%-25%	11.5 volts or less	Needs Charge	At least 20 hours

Cleaning and Storage

See page 119 for the part numbers of Polaris products.

Cleaning the ATV

Keeping your ATV clean will not only improve its appearance but it can also extend the life of various components. With a few precautions, your ATV can be cleaned much like an automobile.

Washing the ATV

The best and safest way to clean your ATV is with a garden hose and a pail of mild soap and water. Use a professional type washing mitten, cleaning the upper body first and the lower parts last. Rinse with water frequently and dry with a chamois to prevent water spots.

NOTE: If warning and safety labels are damaged, contact your a Polaris dealer for free replacement.

Polaris does not recommend the use of a high pressure type car wash system for washing the ATV. If a high pressure system is used, exercise extreme care to avoid water damage to the wheel bearings, transmission seals, body panels, brakes and warning labels.

NOTE: Grease all zerk fittings immediately after washing, and allow the vehicle to run for a while to evaporate any water that may have entered the engine or exhaust system.

Waxing the ATV

Your ATV can be waxed with any non-abrasive automotive paste wax. Avoid the use of harsh cleaners since they can scratch the body finish.

CAUTION

Certain products, including insect repellants and chemicals, will damage plastic surfaces. Use caution when using these products near plastic surfaces.

Cleaning and Storage

Storage Tips

See page 119 for the part numbers of Polaris products.

CAUTION

Starting the engine during the storage period will disturb the protective film created by fogging and damage could occur. Never start the engine during the storage period.

Clean the Exterior

Make necessary repairs and then clean the ATV thoroughly with mild soap and warm water to remove all dirt and grime. Don't use harsh detergents or high pressure washers. Some detergents deteriorate rubber parts. Use dish soap type cleaners only. High pressure washers may force water past seals.

Stabilize the Fuel

Fill the fuel tank. Add Polaris Carbon Clean Fuel Treatment or Polaris Fuel Stabilizer. Follow the instructions on the container for the recommended amount. (Carbon clean will also reduce the possibility of bacterial growth in the fuel system.) Allow 15-20 minutes of operation for the stabilizer to disperse through the fuel in the tank and carburetor. Turn the fuel valve off and drain the carburetor bowl.

Oil and Filter

Warm the engine and change the oil and filter.

Air Filter / Air Box

Inspect and clean or replace the pre-cleaner and air filter. Clean the air box and drain the sediment tube.

Breather Filter

Inspect and clean or replace the breather filter.

Fluid Levels

Inspect the following fluid levels and change if necessary: front gearcase; transmission; brake fluid (change every two years or as required if fluid looks dark or contaminated).

Drain the Recoil Housing

Remove the recoil housing drain plug and drain any moisture.

Cleaning and Storage

Storage Tips

See page 119 for the part numbers of Polaris products.

Fog the Engine

Remove the spark plug and add 2-3 tablespoons of Premium 4 Synthetic 0W40 engine oil. To access the plug hole, use a section of clear 1/4" hose and a small plastic squeeze bottle filled with the pre-measured amount of oil.

NOTE: Do this carefully! If you miss the plug hole, oil will drain from the spark plug cavity into the hole at the front of the cylinder head, and appear to be an oil leak. Install the spark plug and pull the engine over slowly with the recoil starter. Oil will be forced in and around the piston rings and ring lands, coating the cylinder with a protective film of fresh oil.

If you choose not to use Polaris Fogging Oil, perform the following procedure.

- 1. Support the front end of the machine so the engine is level or tilted slightly rearward.
- 2. Remove the spark plug(s). Rotate the piston to BDC and pour approximately two ounces of Polaris oil into the cylinder.
- 3. Apply dielectric grease to the inside of the spark plug cap and install the cap onto the plug.
- 4. Turn the engine over several times to ensure coverage of piston rings, cylinder walls and crankshaft bearings.
- 5. Treat the fuel system with Polaris Carbon Clean.
- 6. If Polaris fuel system additive is not used, fuel tank, fuel lines, and carburetor should be completely drained of gasoline. To eliminate any fuel remaining in the carburetor, run the engine until it stops.

Lubricate

Inspect all cables and lubricate with Polaris Cable Lubricant. Follow lubrication guidelines in the maintenance section of the service or owner's manual to completely grease and lubricate the entire vehicle with Polaris Premium All Season Grease.

Cleaning and Storage

Storage Tips

Battery Storage

Remove the battery from the vehicle and ensure that it's fully charged before placing it in storage. See page 111 for instructions.

Engine Anti-Freeze

Test engine coolant strength and change if necessary. Coolant should be replaced every two years.

Storage Area/Covers

Set the tire pressure and safely support the ATV with the tires 1-2" off the ground. Be sure the storage area is well ventilated, and cover the machine with a genuine Polaris ATV cover.

NOTE: Do not use plastic or coated materials. They do not allow enough ventilation to prevent condensation, and may promote corrosion and oxidation.

Transporting the ATV

Follow these procedures when transporting the vehicle.

- 1. Turn off the engine and remove the key to prevent loss during transporting.
- 2. Always place the transmission in park and lock the parking brake.
- 3. Turn the fuel valve off.
- 4. Be sure the fuel cap, oil cap and seat are installed correctly.
- 5. Always tie the frame of the ATV to the transporting unit securely using suitable straps or rope.

Cleaning and Storage Chrome Wheel Care (if equipped)

Proper maintenance will protect chrome wheels from corrosion, preserve wheel life and ensure a "like new" appearance for many years.

- 1. Wash chrome rims frequently. Use a mild detergent to remove any salt, dirt, mud or grime. Never use abrasive cleaners on plated or painted surfaces.
- 2. Polish the clean chrome wheels periodically. Use an automotive grade chrome polish.
- 3. Routinely and liberally apply a weather resistant wax to each polished chrome wheel. Choose a product suitable for chrome finishes. Read and follow the product labels and instructions.
- 4. Chrome wheels exposed to road salt (or salt in the air in coastal areas) are more susceptible to corrosion if not properly cleaned. Clean chrome wheels more often if they're exposed to salt or other corrosive elements.

Removing Corrosion

If light rust is found on the chrome finish, use steel wool (#0000-OTT grade) to remove it. Gently rub the affected areas with the steel wool until the corrosion has been removed. Clean and polish the wheel as outlined above.

- NOTES -

POLARIS PRODUCTS

Part No.	Description	
	Engine Lubricant	
2870791	Fogging Oil (12 oz. Aerosol)	
2871281	Premium 4 Synthetic 0W-40 (4-Cycle) Engine Oil (qt.)	
2871844	Premium 4 Synthetic 0W-40 (4-Cycle) Engine Oil (gal.)	
	Gearcase / Transmission Lubricants	
2873602	Premium AGL Synthetic Gearcase Lube (qt.)	
2873603	Premium AGL Synthetic Gearcase Lube (gal.)	
2871653	Premium ATV Angle Drive Fluid (8 oz.)	
2872276	Premium ATV Angle Drive Fluid (2.5 gal.)	
2870465	Pump for Gallon Jug	
2871654	Premium Demand Drive Hub Fluid (8 oz.)	
2872277	Premium Demand Drive Hub Fluid (2.5 gal.)	
	Grease / Specialized Lubricants	
2871322	Premium All Season Grease (3 oz. cartridge)	
2871423	Premium All Season Grease (14 oz. cartridge)	
2871460	Starter Drive Grease	
2871515	Premium U-Joint Lube (3 oz.)	
2871551	Premium U-Joint Lube (14 oz.)	
2871312	Grease Gun Kit	
2871329	Dielectric Grease (Nyogel™)	
2872073	Chain Lube (6.25 oz. aerosol)	
2872348	Chain Lube (16 oz. aerosol)	
	Coolant	
2871323	60/40 Coolant (gal.)	
2871534	60/40 Coolant (qt.)	
Additives / Miscellaneous		
2872889	Brake and Clutch Cleaner	
2871326	Carbon Clean Plus (12 oz.)	
2870652	Fuel Stabilizer (16 oz.)	
2870990	DOT3 Brake Fluid	
2872893	Engine Degreaser	
2871956	LOCTITE 565 Thread Sealant	

Drive Belt and Cover Problems			
Possible Cause	Solution		
Driving the ATV onto a pickup or tall trailer in high range.	Shift transmission to low range during loading of the ATV to prevent belt burning.		
Starting out going up a steep incline.	When starting out on an incline, use low range or dismount the ATV (after first applying the park brake) and perform the K-turn as described on page 64.		
Driving at low RPM or low ground speed (at approximately 3-7 MPH).	Drive at a higher speed or use low range more frequently. The use of low range is highly recommended for cooler PVT operating temperatures and longer component life.		
Insufficient warm-up of ATVs exposed to low ambient temperatures.	Warm the engine at least 5 minutes. With the transmission in park, advance the throttle to about 1/8 throttle in short bursts, 5 to 7 times. The belt will become more flexible and prevent belt burning.		
Slow and easy clutch engagement.	Use the throttle quickly and effectively for efficient engagement.		
Towing/pushing at low RPM/low ground speed.	Use low range only.		
Utility use/plowing snow, dirt, etc.	Use low range only.		
Stuck in mud or snow.	Shift the transmission to low range, and carefully use fast, aggressive throttle application to engage clutch. WARNING: Excessive throttle may cause loss of control and vehicle overturn.		
Climbing over large objects from a stopped position.	Shift the transmission to low range, and carefully use fast, brief, aggressive throttle application to engage clutch. WARNING: Excessive throttle may cause loss of control and vehicle overturn.		
Belt slippage from water or snow ingestion into the PVT system.	Shift the transmission to park. Using the throttle, vary the engine RPM from idle to full throttle. Repeat several times as required. During this procedure, the throttle should not be held at the full position for more than 10 seconds. Clutch seals should be inspected for damage if repeated leaking occurs.		
Clutch malfunction.	Contact your Polaris dealer for inspection of clutch components.		
Poor engine performance.	Check for fouled plugs or foreign material in gas tank, fuel lines, or carburetor. Contact your dealer for service.		

Contact your Polaris dealer for service if you're unable to identify solutions using the following charts.

Engine Doesn't Turn Over

Possible Cause	Solution
Tripped circuit breaker	Reset the breaker
Low battery voltage	Recharge battery to 12.5 VDC
Loose battery connections	Check all connections and tighten
Loose solenoid connections	Check all connections and tighten

Engine Turns Over, Fails to Start

Possible Cause	Solution	
Out of fuel	Turn fuel valve to reserve, refuel	
Clogged fuel valve or filter Inspect and clean or replace		
Water is present in fuel	Drain the fuel system and refuel	
Fuel valve is turned off	Turn the fuel valve on	
Old or non-recommended fuel	Replace with new fuel	
Fouled or defective spark plug(s)	Inspect plug(s), replace if necessary	
No spark to spark plug	Inspect plug(s), verify stop switch is on	
Crankcase filled with water or fuel	Immediately see your Polaris dealer	
Overuse of choke	Inspect, clean and/or replace spark plugs	
Clogged fuel filter	Replace the filter	
Low battery voltage	Recharge battery to 12.5 VDC	
Mechanical failure	See your Polaris dealer	

Engine Pings or Knocks

Possible Cause	Solution
Poor quality or low octane fuel	Replace with recommended fuel
Incorrect ignition timing	See your Polaris dealer
Incorrect spark plug gap or heat range	Set gap to specs or replace plugs

Engine Backfires

Possible Cause	Solution
Weak spark from spark plugs	Inspect, clean and/or replace spark plugs
Incorrect spark plug gap or heat range	Set gap to specs or replace plugs
Old or non-recommended fuel	Replace with new fuel
Incorrectly installed spark plug wires	See your Polaris dealer
Incorrect ignition timing	See your Polaris dealer
Mechanical failure	See your Polaris dealer

Engine Runs Irregularly, Stalls or Misfires

Possible Weak Spark Cause	Solution	
Fouled or defective spark plugs	Inspect, clean and/or replace spark plugs	
Worn or defective spark plug wires	See your Polaris dealer	
Incorrect spark plug gap or heat range	Set gap to specs or replace plugs	
Loose ignition connections	Check all connections and tighten	
Water present in fuel	Replace with new fuel	
Low battery voltage	Recharge battery to 12.5 VDC	
Kinked or plugged fuel vent line	Inspect and replace	
Incorrect fuel	Replace with recommended fuel	
Clogged air filter	Inspect and clean or replace	
Reverse speed limiter malfunction	See your Polaris dealer	
Electronic throttle control malfunction	See your Polaris dealer	
Other mechanical failure	See your Polaris dealer	
Possible Lean Fuel Mixture Cause	Solution	
Low or contaminated fuel	Add or change fuel, clean the fuel system	
Low octane fuel	Replace with recommended fuel	
Clogged fuel filter	Replace filter	
Incorrect jetting	See your Polaris dealer	
Possible Rich Fuel Mixture Cause	Solution	
Overuse of choke	Inspect, clean and/or replace spark plugs	
Fuel is very high octane	Replace with lower octane fuel	
Incorrect jetting See your Polaris dealer		

Engine Stops or Loses Power

Possible Cause	Solution	
Out of fuel	Turn fuel valve to reserve, refuel	
Kinked or plugged fuel vent line	Inspect and replace	
Water present in fuel	Replace with new fuel	
Overuse of choke	Inspect, clean and/or replace spark plugs	
Fouled or defective spark plugs	Inspect, clean and/or replace spark plugs	
Worn or defective spark plug wires	See your Polaris dealer	
Incorrect spark plug gap or heat range	Set gap to specs or replace plugs	
Loose ignition connections	Check all connections and tighten	
Low battery voltage	Recharge battery to 12.5 VDC	
ncorrect fuel Replace with recommended fuel		
Clogged air filter Inspect and clean or replace		
Reverse speed limiter malfunction	See your Polaris dealer	
Electronic throttle control malfunction See your Polaris dealer		
Other mechanical failure See your Polaris dealer		
Overheated engine	Clean radiator screen and core if equipped Clean engine exterior See your Polaris dealer	

ATP 330 4X4			
Gross Vehicle Weight	1300 lbs./590 kg		
Fuel Capacity	3.25 gal./12.3 l		
Towing Capacity	1000 lbs./454 kg		
Hitch Tongue Capacity	100 lbs./45.4 kg (rear box capacity and tongue weight not to exceed 250 lbs./113 kg)		
Front Rack & Compartment Capacity	90 lbs./40.8 kg		
Rear Box Capacity	250 lbs./113 kg		
Overall Length	91 in./231 cm		
Overall Width	46 in./116.8 cm		
Overall Height	46 in./116.8 cm		
Wheelbase	56 in./142 cm		
Ground Clearance	6.5 in./16.5 cm		
Dry Weight	719 lbs./326 kg		
Minimum Turning Radius	75 in./190.5 cm unloaded		
Transmission Oil Capacity	13.5 oz./400 ml		
Front Gearcase Oil Capacity	5 oz./148 ml		
Rear Gearcase Oil Capacity	16 oz./473 ml		
Engine Oil Capacity	1.9 qts./1.8 l		
Engine	ES320PFE103		
Displacement	329 cc		
Bore x Stroke	78.5 x 68		
Pilot Jet	42.5		
Main Jet	122.5		
Needle Jet	P-4M		
Jet Needle	48B48-3 (3rd clip)		
Pilot Screw	2 Turns Out (Initial starting point, settings may vary for each ATV)		
Alternator Output	200 w @ 5000 rpm		
Compression Ratio	9.2:1 Full Stroke		
Starting System	Electric		
Carburetor	1/BST34 (CV Type)		
Ignition System	CDI (Analog)		
Ignition Timing	30° ± 2° @ 5000 RPM		
Spark Plug / Gap	NGK BKR6E / .036 in/0.9 mm		
Lubrication System	Wet Sump		

ATP 330 4X4		
Driving System Type	PVT	
Shift Type	Side Lever (H/L/N/R/P)	
Gear Reduction - Low	11.57:1	
Gear Reduction - Reverse	6.84:1	
Gear Reduction - High	4.41:1	
Drive Ratio - Front	3.7:1	
Drive Ratio - Final	3.08:1	
Tire Size - Front	24 x 8 - 12	
Tire Size - Rear	24 x 11 - 12	
Tire Pressure- Front	5 psi	
Tire Pressure- Rear	5 psi	
Front/Rear Brakes	Hydraulic Disc	
Auxiliary Brake	Hydraulic Disc	
Parking Brake	Hydraulic lock, all wheel	
Headlight	Hi/Low 30 watt	
Taillights	Two 12v/3.8 watt	
Brake Light	Two 12.8v/37 watt	
Instrument Cluster	LCD	

Jetting (ATP 330)

Altitude	AMBIENT TEMPERATURE	Below 40° F Below 5° C	+40°Fand above +5°C to & above
Meters (Feet)	0-1800 (0-6000)	127.5	122.5
	1800-3700 (6000-12000)	120	115

Clutching (ATP 330)

Altitude		Shift Weight	Drive Clutch Spring	Driven Clutch Spring	Helix*
Meters (Feet)	0-1800 (0-6000)	20-40 PN 5631356	Blue/Gray PN 7042202	Black PN 7041782	41-35° 5133701 2+2
	1800-3700 (6000-12000)	20-38 PN 5631357	Blue/Gray PN 7042202	Black PN 7041782	41-35° 5133701 2+2

ATP 500 4X4			
Gross Vehicle Weight	1500 lbs./680 kg		
Fuel Capacity	3.25 gal./12.3 l		
Towing Capacity	1225 lbs./556 kg		
Hitch Tongue Capacity	120 lbs./54.4 kg (Rear box capacity and tongue weight not to exceed 400 lbs./181 kg)		
Front Rack & Compartment Capacity	90 lbs./40.8 kg		
Rear Box Capacity	400 lbs./181 kg		
Overall Length	91 in./231 cm		
Overall Width	46 in./116.8 cm		
Overall Height	47 in./119.4 cm		
Wheelbase	56 in./142.2 cm		
Ground Clearance	7.0 in./17.8 cm		
Dry Weight	738 lbs./335 kg		
Minimum Turning Radius	75 in./190.5 cm unloaded		
Transmission Oil Capacity	13.5 oz./400 ml		
Front Gearcase Oil Capacity	5 oz./148 ml		
Rear Gearcase Oil Capacity	16 oz./473 ml		
Engine Oil Capacity	2 qts./1.9 l		
Coolant Capacity	2.25 qts./2.1 l		
Engine	EH500PLE203		
Displacement	499 cc		
Bore x Stroke	92 x 75		
Pilot Jet	40		
Main Jet	155		
Needle Jet	Y-0		
Jet Needle	6H25-94-3		
Pilot Screw	2 Turns Out (Initial starting point, settings may vary for each ATV)		
Alternator Output	250 w		
Compression Ratio	10.2:1 Full Stroke		
Starting System	Electric		
Carburetor	1/BST40		
Ignition System	DC CDI		
Ignition Timing	30° ± 1.5° @ 3500 RPM		
Spark Plug / Gap	BKR6E / .028 in/0.7 mm		

ATP 500 4X4			
Lubrication System	Dry Sump		
Driving System Type	PVT		
Shift Type	Side Lever (H/L/N/R/P)		
Gear Reduction - Low	8.66:1		
Gear Reduction - Reverse	5.12:1		
Gear Reduction - High	3.52:1		
Drive Ratio - Front	3.7:1		
Drive Ratio - Final	3.08:1		
Tire Size - Front	25 x 8 - 12		
Tire Size - Rear	25 x 11 - 12		
Tire Pressure- Front	5 psi		
Tire Pressure- Rear	5 psi		
Front/Rear Brakes	Hydraulic Disc		
Auxiliary Brake	Hydraulic Disc		
Parking Brake	Hydraulic lock, all wheel		
Headlight	Single beam/60 watt Grill - 2 single beam/27 watt		
Taillights	Two 12v/3.8 watt		
Brake Light	Two 12.8v/37 watt		
Instrument Cluster	LCD		

Jetting (ATP 500)

Altitude	AMBIENT TEMPERATURE	Below 40° F Below 5° C	+40°Fand above +5°C to & above
Meters (Feet)	0-1800 (0-6000)	160	155
	1800-3700 (6000-12000)	152.5	147.5

Clutching (ATP 500)

Altitude		Shift Weight	Drive Clutch Spring	Driven Clutch Spring	Helix*
Meters	0-1800	10 BH	Blue/Green	White/Yellow	EBS*
(Feet)	(0-6000)	PN 5630711	PN 7041157	PN 7041635	5132751
	1800-3700	10 RH	Blue/Green	White/Yellow	EBS*
	(6000-12000)	PN 5630709	PN 7041157	PN 7041635	5132751

EBS models require no helix / spring adjustment

LIMITED WARRANTY

Polaris Industries Inc., 2100 Highway 55, Medina, MN 55340, gives a SIX MONTH LIM-ITED WARRANTY on all components of the Polaris All Terrain Vehicle (ATV) against defects in material or workmanship. This warranty covers the parts and labor charges for repair or replacement of defective parts which are covered by this warranty. This warranty begins on the date of purchase. This warranty is transferrable to another consumer during the warranty period through a Polaris dealer.

REGISTRATION

At the time of sale, the Warranty Registration Form must be completed by your dealer and submitted to Polaris within ten days. Upon receipt of this registration, Polaris will record the registration for warranty. THE PURCHASER MUST COMPLETE AN ATV SAFETY TRAINING COURSE PROVIDED BY THE DEALER IN ORDER TO HAVE VALID WARRANTY ON THE ATV. No verification of registration will be sent to the purchaser as the copy of the Warranty Registration Form will be the warranty entitlement. If you have not signed the original registration and received the "customer copy", please contact your dealer immediately. NO WARRANTY COVERAGE WILL BE ALLOWED UNLESS YOUR ATV IS REGISTERED WITH POLARIS.

Initial dealer preparation and set-up of your ATV is very important in ensuring trouble-free operation. Purchasing a machine in the crate or without proper dealer set-up will void your warranty coverage.

LIMITATIONS OF WARRANTIES AND REMEDIES

The Polaris limited warranty excludes any failures that are not caused by a defect in material or workmanship. This warranty does not cover accidental damage, normal wear and tear, abuse or improper handling. This warranty also does not cover any ATV that has been altered structurally, modified, neglected, improperly maintained, used for racing, or used for purposes other than for which it was manufactured, or for any damages which occur during trailer transit or as a result of unauthorized service or the use of unauthorized parts. In addition, this warranty does not cover physical damage to paint or finish, stress cracks, tearing or puncturing of upholstery material, corrosion, or defects in parts, components or the ATV due to fire, explosions or any other cause beyond Polaris' control.

This warranty does not cover the use of unauthorized lubricants, chemicals, or fuels that are not compatible with the ATV. The exclusive remedy for breach of this warranty shall be, at Polaris' exclusive option, repair or replacement of any defective materials, or components or products. THE REMEDIES SET FORTH IN THIS WARRANTY ARE THE ONLY REMEDIES AVAILABLE TO ANY PERSON FOR BREACH OF THIS WARRANTY. POLARIS SHALL HAVE NO LIABILITY TO ANY PERSON FOR INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES OF ANY DESCRIPTION, WHETHER ARISING OUT OF EXPRESS OR IMPLIED WARRANTY OR ANY OTHER CONTRACT, NEGLIGENCE, OR OTHER TORT OR OTHERWISE. Some states do not permit the exclusion or limitation of incidental or consequential damages or implied warranties, so the above limitations or exclusions may not apply to you if inconsistent with controlling state law.

LIMITATIONS OF WARRANTIES AND REMEDIES

ALL IMPLIED WARRANTIES (INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE) ARE LIMITED IN DURATION TO THE ABOVE SIX MONTH WARRANTY PERIOD. POLARIS FURTHER DISCLAIMS ALL EXPRESS WARRANTIES NOT STATED IN THIS WARRANTY. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you if inconsistent with controlling state law.

HOW TO OBTAIN WARRANTY SERVICE

If your ATV requires warranty service, you must take it to a Polaris dealer authorized to repair Polaris ATVs. When requesting warranty service you must present your copy of the Warranty Registration form to the dealer. (THE COST OF TRANSPORTATION TO AND FROM THE DEALER IS YOUR RESPONSIBILITY). Polaris suggests that you use your original selling dealer; however, you may use any Polaris Servicing Dealer to perform warranty service.

Please work with your dealer to resolve any warranty issues. Should your dealer require any additional assistance they will contact the appropriate personnel at Polaris.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

If any of the above terms are void because of state or federal law, all other warranty terms will remain in effect.

Lubricants

- 1. Mixing oil brands or using non-recommended oil may cause engine damage. We recommend the use of Polaris engine oil.
- 2. Damage resulting from the use of non-recommended lubricants may not be covered by warranty.

Exported Vehicles

EXCEPT WHERE SPECIFICALLY REQUIRED BY LAW, THERE IS NO WARRANTY OR SERVICE BULLETIN COVERAGE ON THIS VEHICLE IF IT IS SOLD OUTSIDE THE COUNTRY OF THE SELLING DEALER'S AUTHORIZED LOCATION.

This policy does not apply to vehicles that have received authorization for export from Polaris Industries. Dealers may not give authorization for export. You should consult an authorized dealer to determine this vehicle's warranty or service bulletin coverage if you have any questions.

This policy does not apply to vehicles registered to government officials or military personnel on assignment outside the country of the selling dealer's authorized location.

This policy does not apply to Safety Recalls.

How to Get Service

In the Country where your vehicle was purchased:

Warranty or Service Bulletin repairs must be done by an authorized Polaris dealer. If you move or are traveling within the country where your vehicle was purchased, Warranty or Service Bulletin repairs may be requested from any authorized Polaris dealer who sells the same line as your vehicle.

Outside the Country where your vehicle was purchased:

If you are traveling temporarily outside the country where your vehicle was purchased, you should take your vehicle to an authorized Polaris dealer. You must show the dealer photo identification from the country of the selling dealer's authorized location as proof of residence. Upon residence verification, the servicing dealer will be authorized to perform the warranty repair.

If You Move:

If you move to another country, be sure to contact Polaris Customer Assistance and the customs department of the destination country before you move. Vehicles importation rules vary considerably from country to country. You may be required to present documentation of your move to Polaris Industries in order to continue your warranty coverage. You may also be required to obtain documentation from Polaris Industries in order to register your vehicle in your new country.

How to Get Service

If Purchased From A Private Party:

If you purchase a Polaris product from a private citizen outside of the country in which the vehicle was originally purchased, all warranty coverage will be denied.

Notice

If your vehicle is registered outside of the country where it was purchased, and you have not followed the procedure set out above, your vehicle will no longer be eligible for warranty or service bulletin coverage of any kind. (Vehicles registered to Government officials or military personnel on assignment outside of the country where the vehicle was purchased will continue to be covered by the basic warranty.)

For questions call Polaris Customer Assistance:

United States: 1-763-417-8650 Canada: 1-204-925-7100

California Emission Control Warranty Statement Your Warranty Rights and Obligations

The California Air Resources Board and Polaris Industries Inc., 2100 Highway 55, Medina, Minnesota 55340 (herein "POLARIS") are pleased to explain the emission control system warranty on your 2004 and later Large Spark Ignition Engine (herein "LSI engine"). "The California Air Resources Board has designated this engine for this vehicle as an LSI engine which produces 25 and greater horsepower and the vehicle has a six (6) or four (4)-wheel drive and/or a round steering wheel." In California, this LSI engine must be designed, built and equipped to meet the state's stringent anti-smog standards. Polaris must warrant the emission control system on your LSI engine for the period of time described below, provided there has been no abuse, neglect or improper maintenance of your LSI engine.

Your emission control system includes parts such as the carburetor and the ignition system. Also included may be hoses, connectors and other emission-related assemblies.

Where a warrantable condition exists, POLARIS will repair your LSI engine at no cost to you, including diagnosis, parts and labor.

Manufacturer's Warranty Coverage:

The 2004 and later LSI engines are warranted for two (2) years. If any emission related part on your LSI engine is defective, the part will be repaired or replaced by POLARIS.

Owner's Warranty Responsibilities:

- As the LSI engine owner, you are responsible for the performance of the required
 maintenance listed in your Owner's Safety and Maintenance Manual (herein "Owner's Manual"). POLARIS recommends that you retain all receipts covering maintenance on your LSI engine, but POLARIS cannot deny warranty solely for the lack of
 receipts or for your failure to ensure the performance of all scheduled maintenance.
- As the LSI engine owner, you should, however, be aware that POLARIS may deny
 you warranty coverage if your LSI engine or a part has failed due to abuse, neglect,
 improper maintenance or unapproved modifications.
- You are responsible for presenting your LSI engine to a dealer authorized by POLARIS as soon as a problem exists. The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days.

If you have any questions regarding your warranty rights and responsibilities, you should contact the Polaris Warranty Department at 1-763-417-8650.

Limited Warranty

California Only

POLARIS warrants to the owner of 2004 and later LSI engines that the LSI engine (1) has been designed, built, and equipped at the time of manufacture so as to conform with the applicable regulations of the California Air Resources Board and, (2) is free from defects in materials and workmanship which may cause it to fail to conform with those regulations as applicable according to the terms and conditions stated below.

California Emission Control Warranty Statement Warranty Period

This warranty period begins on the date, which the LSI engine is delivered, to the original retail purchaser and ends two years after that date. During this two year period POLARIS warrants to the original retail purchaser and each subsequent purchaser that the LSI engine is free from defect in material and workmanship that can cause the failure of a warranted emission-related part.

What is Covered Under This Warranty

Repair and/or replacement of any warranted emission-related part will be performed at no charge provided the work is performed at an authorized dealer. There will also be no charge for any diagnostic labor performed at an authorized dealer, which leads to the determination that a warranted emission-related part is defective.

Any warranted part which is not scheduled for replacement as required maintenance, or which is scheduled only for regular inspection to the effect of "repair or replace as necessary" shall be warranted for the warranty period. Any warranted part which is scheduled for replacement as required maintenance shall be warranted for the period of time up to the first scheduled replacement of that part. This warranty shall apply only towards the repair, replacement, and/or adjustment of the component parts listed below.

Emission-Related Parts Covered Under This Warranty

- (1) Fuel Metering System
 - (i) Carburetor and internal parts (and/or pressure regulator or fuel injection system).
 - (ii) Air/fuel ratio feedback and control system, if applicable.
 - (iii) Cold start enrichment system, if applicable.
 - (iv) Regulator assy (gaseous fuel, if applicable)
- (2) Air Induction System
 - (i) Intake manifold, if applicable
 - (ii) Air filter
- (3) Ignition System
 - (i) Spark plugs.
 - (ii) Magneto or electronic ignition system.
 - (iii) Spark advance/retard system, if applicable.
- (4) Exhaust manifold, if applicable
- (5) Miscellaneous Items Used in Above Systems
 - (i) Electronic controls, if applicable
 - (ii) Hoses, belts, connectors, and assemblies.
 - (iii) Filter lock assy (gaseous fuel, if applicable)

If an authorized dealer determines that other LSI engine components have been damaged due to the failure of a warranted emission-related part during the warranty period, POLARIS will repair and/or replace the necessary components.

California Emission Control Warranty Statement What is Not Covered Under This Warranty

This warranty does not cover any emission-related part, which malfunctions, fails, or is damaged due to alterations and/or modifications such as changing, adding, or removing parts.

When the LSI engine is being serviced under warranty, POLARIS and any of its authorized dealers shall not be liable for any loss of use of the LSI engine, for any damage to goods, or loss of time or inconvenience. This limited warranty also does not apply to any emission-related part which malfunctions, fails, or is damaged due to failure to follow the maintenance and operating instructions specified in the 2004 and later Owner's Manual including:

- (a) Improper or inadequate maintenance of any warranted emission-related part
- (b) Improper installation, adjustment, or repair of the LSI engine or any warranted emission-related part unless performed by an authorized dealer
- (c) Failure to use recommended fuel as specified in the 2004 and later Owner's Manual
- (d) Repairs and diagnosis performed outside of an authorized dealer
- (e) Use of parts which are not authorized by POLARIS

Maintenance Schedule

The LSI engine owner is responsible for having all scheduled inspection and maintenance services performed at the intervals specified in the 2004 and later Owner's Manual and to retain records of these services as having been performed. These records should be transferred to each subsequent owner of the LSI engine. POLARIS cannot deny a claim solely because there are no records of scheduled maintenance, however, a warranty claim may be denied if the failure to perform the scheduled maintenance and inspection resulted in the failure of a warranted emission-related part. As a minimum, the LSI engine owner is responsible for the scheduled inspection and maintenance described below which are based on the procedures described in the Owner's Manual.

Maintenance Schedule Key

- ▶ Perform these procedures more frequently for vehicles subjected to severe use.
- **E** Emission Control System Service (California)
- Have an authorized Polaris dealer perform these services.

California Emission Control Warranty Statement Maintenance Schedule

Item		Maintenance Interval (whichever comes first)			Remarks
		Hours	Calendar	Miles (Km)	
≜ E	Engine oil level	-	Pre-Ride	1	Make adjustments as needed. See Pre-Ride Checklist on page 52.
ΔE	Air filter, pre-filter	•	Daily	ı	Inspect; clean often
≜ E	Air box sediment tube	1	Daily	1	Drain deposits when visible
ΔE	Air filter, main element	-	Weekly	1	Inspect; replace as needed
≜ E	Engine breather filter (if equipped)	25 H	Monthly	155 (250)	Inspect; replace if necessary
≜ Ε	Engine oil change (break-in)	25 H	1 M	155 (250)	Perform a break-in oil change at one month
■ E	Throttle Cable/ ETC Switch	50 H	6 M	310 (500)	Inspect; adjust; lubricate; replace if necessary
■ E	Choke cable	50 H	6 M	310 (500)	Inspect; adjust; lubricate; replace if necessary
Ε	Carburetor air intake ducts/ flange	50 H	6 M	310 (500)	Inspect ducts for proper sealing/air leaks
≜ E	Engine oil change	100 H	6 M	620 (1000)	Perform a break-in oil change at 25 hours/one month
≜ E	Oil filter change	100 H	6 M	620 (1000)	Replace with oil change
≜ E	Oil tank vent hose	100 H	12 M	620 (1000)	Inspect routing, condition
■ E	Valve clearance	100 H	12 M	620 (1000)	Inspect; adjust
E	Fuel system	100 H	12 M	620 (1000)	Check for leaks at tank cap, lines, fuel valve, filter, pump, carburetor; replace lines every two years
■ E	Fuel filter	100 H	12 M	620 (1000)	Replace yearly
■ E	Spark plug	100 H	12 M	620 (1000)	Inspect; replace as needed
■ E	Ignition Timing	100 H	12 M	620 (1000)	Inspect

California Emission Control Warranty Statement Repair and Replacement of Emission-Related Parts

It is recommended that only LSI engine replacement parts, which have been authorized and approved by POLARIS, should be used in the performance of any warranty maintenance or repairs of emission-related parts. These replacement parts will be provided at no charge if the part is still under warranty.

How to File a Warranty Claim/Where to Get Warranty Service

All repairs qualifying under this Limited Warranty must be performed by a dealer who sold you the LSI engine or a dealer authorized by POLARIS. In the event that any emission-related part is found to be defective during the warranty period, you must notify the Polaris Warranty Department at 1-763-417-8650 and you will be advised of the appropriate dealer where the warranty repair is to be performed.

INDEX

Α	E
Accessories 73 Adjustments 90-100 Age Restrictions 7 Air Filter 101 All Wheel Drive 44-45 Auxiliary Brake 39, 91 AWD 44-45	Electrical Switches
В	F
Battery 110-112 Battery Charging 111-112 Battery Installation 110 Battery Removal 110 Battery Storage 111, 116 Belt Life 42 Brake Fluid 37 Brake Lever 36 Brakes 90 Break-In Period 51	FEATURES AND CONTROLS 33-50 Filter Systems 101 Front Gearcase Oil 86 Front Wheel Hub Tightening 100 Fuel Filter 40 Fuel Safety 41 Fuel Stabilizer 114 Fuel Tank 40 Fuel Valve 40
Breather Filter/Hose (ATP 500) 101	Gear Selector
C	Н
Camber and Caster 93 Carburetor 95 Choke 40 Chrome Wheel Care 117 Cleaning and Storage 113-117 Cleaning the ATV 113 Clutching (ATP 330) 125 Clutching (ATP 500) 127 Cold Weather Operation 54 Coolant (ATP 500) 88 Coolant Level (ATP 500) 89 Cooling System Operation (ATP 500) 88 Corrosion 117 Crankcase Emission Control System 72	Handlebars 94 Hauling Cargo 55-57 Headlight Adjustment, Lower 103 Headlight Housing Replacement 104 Headlight Lamp Replacement, Lower 103 Headlight Lamp Replacement, Pod 102 Helmet 32 High Beam Adjustment 105 High Range 70 Hour Meter 48 I Instrument Cluster 46-50
D	J
Diagnostic Mode49-50Driving Downhill63Driving in Reverse68Driving on Slippery Surfaces60Driving Over Obstacles67Driving Procedures58Driving Safely58-69Driving Through Water65-66Driving Uphill61Dumping Cargo57	Jetting (ATP 330) 125 Jetting (ATP 500) 127 K K K-Turn 64 L Light Switches 34 Lights 102-105 Load Distribution 56
	Low Range

INDEX

M	S
Main Switch	Safety Training 7
MAINTENANCE AND	Side Panel Removal 97
LUBRICATION 73-117	Sidehilling
Maintenance Record 78	Spark Arrestor 72, 108
Making Turns	Spark Plug
N	Removal and Replacement 106
IN	Spark Plugs
Noise Emission Control System 72	SPECIFICATIONS 124-127
0	Speedo Mode Switch
_	Starting a Cold Engine
Odometer 48	Starting a Warm Engine 54
Oil Change (ATP 330) 83-84	Starting the Engine 53-54
Oil Change (ATP 500) 80-82	Steering Assembly
Oil Check (ATP 330) 83	Stop Switch
Oil Check (ATP 500) 80	Storage Tips
Oil Cooler (ATP 330)	Т
Oil Pump Priming 82	•
Oil, Engine 79-84	TABLE OF CONTENTS
Oil, Front Gearcase	Tachometer 48
Oil, Rear Gearcase	Taillight/Brakelight
Oil, Transmission	Lamp Replacement
OPERATION 51-71	Throttle Lever
Operator Safety 7-27 Override Switch 33	Tire Tread Depth
Override Switch	Toe Alignment
Р	Towing Capacities
Parking Brake	Transmission Gear Selector 42
Parking on an Incline	Transmission Oil
Periodic Maintenance Chart 73-76	Transporting the ATV
POLARIS PRODUCTS	Trip Meter
Pre Ride Inspection	TROUBLESHOOTING 120-123
Premium 4 Synthetic Oil	Turning Around on a Hill 64
PVT Drying 71	•
PVT System 70-71	V
•	VEHICLE IDENTIFICATION
R	NUMBERS 6
Radiator Coolant Level (ATP 500) 89	Vehicle Immersion 107
Rear Gearcase Oil 87	W
Rear Spring	
Recoil Housing 109	WARRANTY 128-135
Recoil Starter	Washing the ATV
Rider Information Center 47-50	Waxing the ATV
S	WELCOME 3
_	Wheel Installation
Safe Riding Gear	Wheel Nut Torque Specifications 99
SAFETY	Wheel Removal
Safety Decals and Locations 28-31	